

Operation Manual

PRODUCT NAME

MICRO MIST SEPARATOR REGULATOR

MODEL/ Series

 $AWD20-(F,N)01 \sim (F,N)02(B,C,E,G,H)(-1,2,6,C,J,N,R,Z)$ $AWD30-(F,N)02 \sim (F,N)03(B,C,D,E,G,H)(-1,2,6,8,J,N,R,W,Z)$ $AWD40-(F,N)02 \sim (F,N)04(B,C,D,E,G,H)(1,2,6,8,J,N,R,W,Z)$

SMC Corporation

Contents PAGE 1~5 1. SAFETY INSTRUCTIONS 2. APPLICATION 6 3. SPECIFICATIONS 6 4. HOW TO ORDER 6 7 5. MAXIMUM APPLICABLE FLOW RATE 6. TROUBLESHOOTING 8 7. CONSTRUCTION / PARTS LIST 9 8. BOWL ASSEMBLY SPECIFICATIONS 10~12 9. HOW TO ORDER 13~15 10. DISASSEMBLY DRAWING 16~18 11. DIMENSIONS 19





MICRO MIST SEPARATOR REGULATOR Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage.

These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger."

They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC). Japan Industrial Standards (JIS)*1) and other safety regulations*2).

*1) ISO 4414: Pneumatic fluid power -- General rules relating to systems

ISO 4413: Hydraulic fluid power -- General rules relating to systems

IEC 60204-1: Safety of machinery -- Electrical equipment of machines (Part 1: General requirements)

ISO 10218-1992: Manipulating industrial robots -- Safety

JIS B 8370: General rules for pneumatic equipment.

JIS B 8361: General rules for hydraulic equipment.

JIS B 9960-1: Safety of machinery – Electrical equipment for machines. (Part 1: General requirements)

JIS B 8433-1993: Manipulating industrial robots - Safety. etc.

*2) Labor Safety and Sanitation Law, etc.

Caution Operator error could result in injury or equipment damage.

Warning

Operator error could result in serious injury or loss of life.

Danger

In extreme conditions, there is a possibility of serious injury or loss of life.

Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results.

The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product.

This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly.

The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.

The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.

When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.

Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
 - 1) Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2) Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
 - 3) An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4) Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.



! Caution

The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

The warranty period of the product is 1 year in service or 1.5 years after the product is delivered. Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.

For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided.

This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.

Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.

Compliance Requirements

When the product is exported, strictly follow the laws required by the Ministry of Economy, Trade and Industry (Foreign Exchange and Foreign Trade Control Law).

Precautions for design



WARNING

- (1) External parts including the bonnet, handle, cover are made of resin. Organic solvents including synthetic fluid, chemicals including acetone, alcohol, ethylene chloride, sulphuric acid, nitrate, hydrochrolic acid, cutting oil, kerosene, gasoline, lock material of screw are harmful. Don't use the regulator where containing those.
- ② Avoid the application where charge and discharge of pressure to standard bowl is switched frequently. The bowl may be broken. For this kind of application, the metal bowl is recommended.
- 3 Consult SMC if no leakage is allowed due to the environment, or operating fluid is not air
- 4 Protect from ultra violet ray and radiation heat by shield.
- (5) Safety device needs to be installed if output pressure exceeding set pressure lead to cause the breakage of outlet device and equipment or malfunction.



CAUTION

- 1 The use outside specifications is prohibited.
- 2 Air consumption from release port is 0.1L/min(ANR) or less.
- 3 AD17 and 27 with auto drain may leak the drain pooled there during exhaust of pressure. (This leakage is allowed in their constructions and not failure.) Be sure to connect piping for drain.

Selection



WARNING

- ① Mineral grease used for internal sliding surface and packing may leak to the outlet. Please contact SMC if this is a problem.
- 2 Residual pressure(outlet pressure) is not released even if releasing inlet pressure. Please install the check valve separately in parallel when you eliminated residual pressure.
- 3 Long absence of operation or operation with outlet circuit sealed or balance circuit may cause pressure fluctuation in outlet set pressure. Please consult SMC if this is a problem.
- 4 Set pressure of outlet pressure shall be 85% or less of inlet pressure. Pressure over 85% makes operation susceptible to flow and inlet pressure which lead to cause unstable operation.
- (5) Maximum set pressure range in the spec. has margin. Pressure set may be higher than the maximum value.
- 6 If regulator is used with circuit which require high exhaust sensitivity or set precision, please consult SMC.
- N.O type auto drain should be used under the following requirements to avoid operating failure. Output of compressor: 0.75kW or more.

Discharged flow rate: 100L/min (ANR) or more.

If multiple auto drains are used, confirm used compressor has capacity over the result of multiplying the above capacity and the number of used auto drains.

{For example, in case of two auto drain, the compressor need the capacity over 1.5kW [200L/min (ANR)].}

N.C. type auto drain should be used under the following requirements to avoid operating failure.

Operating pressure: 0.1MPa at min. for AD17 and 27, 0.15MPa at min. for AD37 and 47.

Installation



CAUTION

- ① Connect the regulator ensuring the direction of "IN" and "OUT" for air direction or an arrow. Wrong connection lead to cause malfunction.
- 2 Install vertically so that outlet of drain would turnde downward. Use with the outlet of drain turned lateral or upward causes malfunction.
- ③ Keep the space for maintenance and operation on the top, bottom and front face. The required space is shown on 「11. Dimensions」 (P19).
- 4 Don't drop nor apply impact during transportation or installation. gauge. These lead to cause precision failure of pressure.
- ⑤ Don't install where highly humid or temperature is high. Or pressure gauge may malfunction.

Adjustment



WARNING

- Adjust the pressure ensuring inlet pressure and outlet pressure. Excessive rotation may cause internal parts.
- 2 Operate the pressure adjusting handle manually. Tools may break the handle.

\triangle

CAUTION

- 1 Check primary pressure before setting up.
- 2 For the regulator with the pressure gauge, don't apply pressure over the maximum scale of the pressure gauge in order to protect the gauge.
- 3 Adjust pressure incrementally. Pressure may become lower than set pressure if adjusted by decreasing the value. Rotate the handle clockwise to raise the set pressure. Counterclockwise, reduce the pressure
- 4 Outlet pressure may rise if eliminate the inlet pressure after pressure setting and supply pressure again. The pressure becomes close to the set pressure after air is consumed in outlet.
- ⑤ Outlet pressure might change if uses for a long time. Please confirm set pressure regularly.

Piping



WARNING

- 1 Flash or clean piping before piping to eliminate swarf, cutting oil, solid foreign material. Remaining of these lead to cause malfunction.
- 2 When screw in piping or fitting, avoid entering of chips and sealing materials from piping screws into the inside of equipment. Or malfunction is led to occur. When use sealing tapes, leave 1.5~2 threads of a screw and starts taping.
- 3 Hold the female screw side and screw in piping with recommended tightening torque. Insufficient tightening torque lead to cause loose piping or sealing failure. Excessive torquemay lead to cause screw breakage. Tightening without holding female screw side applies 'excessive force to the piping bracket which lead to cause breakage.

Recommen	ided torque	unit:N•ı	m	
Screw	1/8	1/4	3/8	1/2
Torque	7 ~ 9	12~14	22~24	28~30

- (4) Don't apply any torsional moment, or bending moment except the weight of the regulator itself. External pipings need its support separately. Hard piping like steel tube is susceptible to excessive moment load or vibration. Insert the flexible tube to cancel the influence
- ⑤ Drain guide is not equipped with valve function. Be sure to connect piping for drain. No piping for drain allows the drain and compressed air to exhaust freely. Also, the piping should be performed with drain guide held by spanner to prevent breakage of bowl.
- (6) The piping for drain from auto drain should be connected under the following requirements to avoid operating failure.

AD17, 27: I.D. φ 2.5 (φ 3/32") at min., Length 5m (200") at max.

AD37, 47(N): I.D. ϕ 4 (ϕ 3/16") at min., Length 5m (200") at max.

AD38, 48(N): I.D. φ 6.5 (φ 1/4") at min., Length 5m (200") at max.

Air Source



WARNING

- ① Use clean air. Compressed air containing chemicals, organic solvent, synthetic oil or corrosive gas may lead to cause breakage of parts or malfunction.
- 2 Air containing much drain lead to cause malfunction. Install the air drier or the after-cooler before the mist separator regulator.



CAUTION

1 Please install the air filter in the inlet of the mist separator regulator as Prifilta to avoid stopped up at the early clog of the element.

Maintenance



WARNING

- ① Maintenance or check should be done by following the procedure in the operation manual. Incorrect handling of the product may cause breakage or malfunction of the equipment or device.
- 2 Perform periodical check to find crack, flaw or other deterioration on resin bowl. If any of them is seen, as malfunction is caused, replace with new bowl or metal bowl.
- 3 Check the dirt of resin bowl periodically. If any dirt is seen, replace with new bowl. And if removing off the dirt by washing instead of replacement, never use washing material other than neutral detergent. Otherwise, the bowl is damaged.
- (4) Replace the element before 2 years passed since purchase or pressure drop from initial outlet pressure reaches 0.1MPa. Or the element is broken.
- ⑤ Open and close drain cock manually. Open and close by a too may damage the drain cock.
- 6 Drain the bowl by opening drain cock before the drain level in the bowl reaches the bottom end of the element.



CAUTION

- 1) For First-aid for setting failure or leakage, check the internal valve sliding surface or the valve seat before giving first-aid treatment.
- ② Check the element periodically and replace it with new one if necessary.

 If it is found that secondary pressure lowers or the flow is restricted, check the condition of element.
- ③ The manual exhaust for emergency case can be performed by counterclockwise rotation of the handle in AD17 and 27. (○←direction)

 For AD37, 38, 47 and 48, rotate the drain cock counterclockwise in that case.(○←direction)

2. APPLICATION

This instrument aims at , eliminating excess saturated water,oil of the air line and solid foreign material, pressure controlling of air lines.

3. SPECIFICATIONS

Model	AWD20	AWD30	AWD40		
Port size	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2		
Fluid		Air			
Proof pressure		1.5MPa			
Max. operating pressure		1.0MPa			
Note1) Set pressure range		0.05∼0.85MPa			
^{Note2)} Gauge port size		1/8	1/4		
Relieving pressure	Set pressure plu	s 0.05MPa {When relieving flow	is 0.1L/min(ANR)}		
Ambient and fluid temperature		−5~60°C(Should be no freezing	g)		
Filtration	0.	01µ m(95% particles size collec	tion)		
Note3) Oil mist density at the out side		$MAX.0.1 mg/m^3 (ANR) (= 0.8 ppm)$	1)		
Note4) Flow rate [I∕min(ANR)]	90	180	450		
Drain capacity (cm³)	8	25	45		
Drain guide port size	1/8	1/4	1/4		
Construction	Relieving style				
Weight (kg)	0.44kg	0.59kg	1.25kg		
Note5) Bowl guard	Δ	0	0		

Note1) The range of set pressure for an auto drain (N.O. type): 1 -0.85MPa.

for an auto drain (N.C. type):0.1-0.85MPa(AWD20),0.15-0.85MPa(AWD30/40)

Note2) Square embedded pressure gauge. Without pressure gauge mounting threads.

Note3) When oil mist density of the compressor exhaust is 30mgf/Nm³(ANR).


A little amount of grease is used for bowl O ring and other O rings.

Note4)The set pressure is 0.5MPa. (The rated flow is different according to the set pressure.)

If larger amount of air than the rated flow is supplied, the oil flows into the out side.

Note5) \bigcirc : Combinable to standard \triangle : Combinable to option

4. HOW TO ORDER



Note3)Accossory is packed together and is not mounted.

(With limit indicator)

With float auto drain (N.O.)

With set nut (Panel mounting)

Square embedded pressure gauge

Circular pressure gauge (With limit indicator)

AWD30-40

AWD30-40

AWD20~40 AWD20~40

(Except type C,D,E)


D

Ε

G

Η

5. MAXIMUM APPLICABLE FLOW RATE




6. TROUBLESHOOTING

Refer to "7.CONSTRUCTION" (P9), "10.DISASSEMBLY DRAWING" (P16~P18).

TF	ROUBLE		ON" (P9), "10.DISASSEMBLY DRAWING POSSIBLE CAUSE	J (1	REMEDY	Applicable
Demarcation	Phenomenon Pressure is	1.	Opposite fllow direction or opposite	1.	Check flow diretion and install he	model AWD20~40
	not regulated	2.	installation of regulator. Adjust spring is damaged.	2.	regulator correctly if wrong. Replace the adjust spring.	AWD20~40
		3.	Valve spring is damaged.	3.	Replace the valve spring.	AWD20~40
		4.			Remove the valve guide to clean valve, valve seat and the valve "O" ring. Then, grease up the valve "O" ring and the sliding surface.	AWD20~40
Pressure		5.	Valve rubber seat is damaged.	5.	Replace the valve.	AWD20~40
	Set pressure does not return to zero when pressure handle is	1.	Foreign materials caught in valve seat or valve "O" ring.	1.	Remove the valve guide to clean valve, valve seat and the valve "O" ring. Then, grease up the valve "O" ring and the sliding surface.	AWD20~40
	loosened	2.	Valve rubber seat is damaged.	2.	Replace the valve.	AWD20~40
		3.	Valve spring is damaged.	3.	Replace the valve spring.	AWD20∼40
		4.	Valve adheres to the valve guide.	4.	Wash the sliding surface of valve "O" ring and grease up.	AWD20~40
Flow rate	Large air resistance reduces flow rate.	1.	Clog of the element.	1.	Replace the element.	AWD20∼40
	Air leaks from the bonnet	1.	Diaphragm is damaged.	1.	Replace the diaphragm assembly.	AWD20∼40
	exhaust port	2.	Foreign material is caught in the relieving valve seat.	2.	Clean the relieving valve seat, or replace the diaphragm assembly.	AWD20~40
		3.	Foreign material is caught in the valve seat of valve "O" ring.	3.	Remove the valve guide to clean valve, valve seat and the valve "O" ring. Then, grease up the valve "O" ring and the sliding surface.	AWD20~40
		4.	Valve rubber seat is damaged.	4.	Replace the valve.	AWD20~40
Air leaks		5.	Back pressure exceeding the set pressure is applied to the outlet.	5.	Revise the air circuit so that back pressure does not exceed the set pressure.	AWD20~40
	Air leaks	1.	Loosened bonnet.	1.	Fasten the bonnet.	AWD20~40
	between the bonnet and the body.	2.	Diaphragm is damaged.	2.	Replace the diaphragm assembly.	AWD20~40
	Air leaks from the bowl and the body.	1.	Breakage of "O" ring.	1.	Replace the "O" ring. Grease up before assembling.	AWD20∼40
	Air leaks from the bowl.	1.	Breakage of bowl.	1.	Replace the bowl assembly or with metal bowl.	AWD20~40
	Air leaks from the drain cock.		The foreign matter caught in the valve of the drain cock. the drain cock.		Open the drain cock for a few seconds for blowing.	AWD20~40
		2.	Breakage of the seating part of the drain cock	2.	Replace the bowl assembly.	AWD20∼40
	Draining isn't perfumed though the drain cock is opened.	1.	Clock of outlet of the drain cock due to solid foreign matter etc.	1.	Replace the bowl assembly.	AWD20∼40
Operational	Too much drain comes from the piping of secondary side.	1.	Drain level in the bowl reaches the bottom end of the element.	1.	Draining and replace the element.	AWD20∼40

Note) The grease used recommends Mitsubishi diamond multipurpose No.2.

7. CONSTRUCTION / PARTS LIST



Component Parts

	Decembries	Mat	erial	Note
	Description	AWD20	AWD30-40	Note
1	Body	Zinc die cast	Aluminium die cast	Painted platinum silver
2 Bonnet		P	MC	Painted black

Option / Replacement Parts

Opt	Option/ Replacement Parts									
No.	Description	Throad	Poud	Ontion	Matarial		Part no.			
INO.	Description	Thread	DOWI	Option	Material	AWD20	AWD30	AWD40		
3	Valve assembly		_	_	HNBR	AWM20P-090AS	AWM30P-090AS	AWM40P-090AS		
4	Element assembly	_	_	_	_	AFD20P-060AS	AFD30P-060AS	AFD40P-060AS		
(5)	Diaphragm assembly	_	_	_	Wheatherproof NBR	AR20P-150AS	AR30P-150AS	AR40P-150AS		
		1	_	Ν	Wheatherproof NBR	AR20P-150AS-N	AR30P-150AS-N	AR40P-150AS-N		
6	Bowl O ring		_	_	NBR	C2SFP-260S	C3SFP-260S	C4SFP-260S		
7	Bowl assembly		-							
	Auto drain (N.C.)				Refer to \(\bar{8} \). SPECIFICA	TIONS OF BOWL ASS	EMBLY」(P9∼P11).			
	Auto drain (N.O.)									
8	Note1)Bracket assembly	1	_	_	Steel plate POM	AW20P-270AS	AR30P-270AS	AR40P-270AS		
(9)	Set nut	1	_	_	POM	AR20P-260S	AR30P-260S	AR40P-260S		
10	^{Note2)} Square embedded	1	_	_			GC3-10AS			
	pressure gauge	NPT	_	Ζ	_		GC3-P10AS			
11)	Pressure gauge cover	_	_	_	_		GC3P-010AS			
12	Circular pressure gauge	Rc	_	_	_	Note3) G3	6-10-01	Note4) G46-10-02		
		NPT		_	_	Note3) G36	6-10-N01	Note4) G46-10-N02		
			_	Z	_	Note3) G36	-P10-N01	Note4) G46-P10-N02		
		G	_	_	_	Note3) G3	6-10-01	Note4) G46-10-02		
13	Pressure gauge	Rc	_	_	Aluminium die cast	AR20P-3	10AS-01	AR20P-310AS-02		
	adaptor assembly	NPT	_	_	Aluminium die cast	AR20P-3	10AS-N01	AR20P-310AS-N02		
		G	_	_	Aluminium die cast	AR20P-3	10AS-F01	AR20P-310AS-F02		
14)	Plug assembly	Rc	_	_	_	AR20P-3	20AS-01	AR40P-320AS-02		
		NPT	_	_	_	AR20P-320AS-N01 AR40P-320AS-N		AR40P-320AS-N02		
		G	_	_	_	AR20P-320AS-F01 AR40P-320AS		AR40P-320AS-F02		
15	Plug	Rc	_	_	PA	AR20P-370AS-01 AR20P-370AS-0		AR20P-370AS-02		
		NPT	_	_	PA	AR20P-370AS-N01 AR20P-370AS-I		AR20P-370AS-N02		
		G	_	_	PA	AR20P-370AS-01 AR20P-370AS		AR20P-370AS-02		
16	Blanking plate assembly	1	_	_			AR20P-250AS			

Note1) Bracket and Set nut assembly.

Note2) With O ring (1 piece) and Mounting screws(2 pcs). For 0.2MPa part number: GC3-2AS/GC3-P2AS(NPT•Z).

Note3) For 0.2MPa part number: $G36-2-01(Rc)/G36-2-N01(NPT)/G36-P2-N01(NPT \cdot Z)$.

Note4) For 0.2MPa part number: $G46-2-02(Rc)/G46-2-N02(NPT)/G46-P2-N02(NPT \cdot Z)$.

Note5) The number in the table is corresponding to the number in structural drawing (avobe-mentioned figure) and $\texttt{ 8.SPECIFICATIONS OF BOWL ASSEMBLYJ(P9\simP11),} \\ \texttt{ $1.0.DISASSEMBLY DRAWINGJ (P16\simP18) }$

8. BOWL ASSEMBLY SPECIFICATIONS

1)AWD20 Bowl assembly

Accessory	_	_	Note2)	С	_	-
Option	_	6	_	6	J	6J
External appearance drawing Part No.	Option Option	8	Option □ □ □ □ Port thread ⑦ Part No. □ Rc □ AD27 □ NPT □ AD27(-Z) □ □ AD27(-Z) □ □ AD27(-Z) □ □ AD27-6 □ AD27-6 □ NPT □ AD27-6(Z) □ AD27	M5X0.8	Option「J」	1/8 HEX. 14
Accessory	-	_	Note2)	С	_	-
Option	С	6C	С	6C	CJ	6CJ
External appearance drawing Part No.	OptionΓC J Port thread ⑦Part No. Rc C2SF-C NPT C2SF-C(Z) OptionΓ6C J Port thread ⑦Part No. Rc C2SF-6C NPT RC C2SF-6C(Z)	B B	Option C J Port thread	M5 X O . 8	Option □ CJ □ Port thread ⑦ Part No. Rc C2SF-CJ G C2SFF-CJ NPT C2SFN-CJ(Z) Option □ 6CJ □ Port thread ⑦ Part No. Rc C2SF-6CJ G C2SFF-6CJ NPT C2SFN-6CJ(Z)	1/8 HEX. 14
Accessory	-	_	Note2)	С	_	-
Option	2	2	2		2	J
External appearance drawing Part No.	Port thread ⑦ Part No. Rc		Port thread (7)Part No. Rc	M5X0.8	Port thread ⑦Part No. Rc C2SF-2J G C2SFF-2J NPT C2SFN-2J(Z)	1/8 HEX. 14

Note1) B in the table shows the total length of the product. Refer to "11. DIMENTIONS" (P19).

Note2) The lowest pressure is 0.1MPa.

Note3) The lowest pressure is 0.1MFa.

Note3) The lowest pressure is 0.1MFa.

Note3) The part with no. ① includes ⑥ Bowl O ring. Refer to "10. DISASSEMBLY DRAWING" (P16~P18).

Note4) "Z" in the part number② is a option, and the unit of the pressure and the temperature are PSI and ° F.

Note5) Refer to "4. HOW TO ORDER" (P6) for an accesories symbol and option symbol.

2) Bowl assembly/Auto drain for AWD30

Accessory	_		Note2)	Note2)	_	_
Option	_	6	- 6	– 6	J 6J	W 6W
External appearance drawing Part no.	Option 「-」 (Standard) Port thread ⑦Part no. Rc C3SF NPT C3SF(-Z) Option 「6」 Port thread ⑦Part no. Rc C3SF-6 RC C3SF-6 NPT C3SF-6(Z)		Option 「-」 Port thread ⑦Part no. D Rc AD37	Option 「-」 Port thread ⑦Part no. D Rc AD38 φ 10 NPT AD38N(-Z) φ 3/8" D: APPLICABLE TUBE EXTERNAL DIAMETER Option 「6」 Port thread ⑦Part no. D Rc AD38-6 φ 10 G AD38-6 φ 10 NPT AD38N-6(Z) φ 3/8" D: APPLICABLE TUBE EXTERNAL DIAMETER	Option 「J」 Port thread ⑦Part no. Rc C3SF-J G C3SFF-J NPT C3SFN-J(Z) Option 「6J」 Port thread ⑦Part no. Rc C3SF-6J G C3SFF-6J NPT C3SFN-6J(Z)	Option 「W」 Port thread ⑦Part no. D Rc C3SF-W G T0604 NPT C3SF-W(Z) D: APPLICABLE TUBE Option 「6W」 Port thread ⑦Part no. D Rc C3SF-6W G T0604 NPT C3SF-6W(Z) D: APPLICABLE TUBE
Accessory	_		Note2) C	Note2)	-	
Option	2		2	2	2J	-
External appearance drawing Part no.	Port thread ⑦Part no. Rc C3SF-2 G NPT C3SF-2(Z)		Port thread ⑦Part no. D Rc AD37-2 φ 10 NPT AD37N-2(Z) φ 3/8" D: APPLICABLE TUBE EXTERNAL DIAMETER	Port thread ⑦Part no. D Rc AD38-2 φ 10 NPT AD38N-2(Z) φ 3/8" D: APPLICABLE TUBE EXTERNAL DIAMETER	Port thread ⑦Part no. Rc C3SF-2J G C3SFF-2J NPT C3SFN-2J(Z)	
Accessory	_		Note2)	Note2)	_	Metal bowl with sight glass
Option	8		8	8	8J	
External appearance drawing Part no.	Port thread ⑦Part no. Rc G NPT C3LF-8(Z)		Port thread ⑦Part no. Rc AD37-8 G NPT AD37N-8(Z)	Port thread Part no. D Rc AD38-8 Q 10 NPT AD38N-8(Z) Q 3/8" D: APPLICABLE TUBE EXTERNAL DIAMETER	Port thread ⑦Part no. Rc C3LF-8J G C3LFF-8J NPT C3LFN-8J(Z)	34.5

Note 1) B in the table shows full dimensions of the product. Refer to Γ 11. DIMENSIONS (P19).


Note 2) Min. operating pressure is 0.15MPa for N.C. type and 0.1MPa for N.O. type.

Note 3) The part with no. ⑦ includes ⑥ Bowl O ring. Refer to ☐10. DISASSEMBLY DRAWING」(P16~P18).

Note 4) "Z" of the part with no. 7 is semi-standard for indicated unit of pressure and temperature, which is PSI and F

Note 5) The symbol for option and semi-standard are described as \(\begin{align*} 4. \text{ HOW TO ORDER} \end{align*} (P6). \)

3) Bowl assembly/Auto drain for AWD40



Note 1) B in the table shows full dimensions of the product. Refer to Γ 11. DIMENSIONS Γ (P19).

Note 2) Min. operating pressure is 0.15MPa for N.C. type and 0.1MPa for N.O. type.

Note 3) The part with no. ⑦ includes ⑥ Bowl O ring. Refer to 「10. DISASSEMBLY DRAWING」(P16~P18).

Note 4) "Z" of the part with no. (7) is semi-standard for indicated unit of pressure and temperature, which is PSI and F

Note 5) The symbol for option and semi-standard are described as [4. HOW TO ORDER](P6).

9. HOW TO REPLACE

Warning

Before replacement, ensure that the regulator is not pressurized.

Rotate the pressure adjusting handle to zero.

Replace refering to "10. DISASSEMBLY DRAWING" (P16~P18).

After replacement, ensure that specified function is satisfied and external leakage is not found before starting operation.

1) Bowl assembly / Element

Applicable model	Process	Procedure	Tools	Check item
	Disassembly	Remove the bowl assembly Hold the bowl assembly by hand and rotate couterclockwise to remove the bowl assembly. If the bowl assembly is tightened too much to be removed, use hook spanner until it can be loosened by hand.	Hook spanner Nominal:34/38	_
		Remove the element Hold the element with a spanner to rotate it counterclockwise and remove the element.	Spanner Nominal : 7	_
AWD20	Assembly	 Mount the element. Hold the element with a spanner to rotate it counterclockwise and remove the element. See check item for referential tightening torque. 	Spanner Nominal : 7	Tightening torque: 0.49±0.05N•m
		4) Mount the bowl assembly. Hold the bowl assembly by hand and rotate clockwise. Do not use tool for mounting because the bowl may be damaged. See check item for referential tightening torque.	I	Refential tightening torque: 2.2 N·m
	Disassembly	Remove the bowl assembly Push the bowl assembly lock button. Lifting the bowl assembly, rotate the assembly 45 degree(right or left) to pull out the assembly.	_	_
		Remove the element Hold the element with a round pliers to rotate it counterclockwise and remove the element.	Round pliers	_
AWD30 AWD40	Assembly	 Mount the element. Hold the element with a round pliers to rotate it counterclockwise and remove the element. See check item for referential tightening torque. 	Round pliers	Tightening torque: AWD30 1.47±0.2N⋅m AWD40 1.96±0.2N⋅m
		4) Mount the bolw assembly. Match the mating mark of the body and the bowl assembly to insert the assembly to the body. Rotate the assembly 45 degree(right or left) until the lock button is tossed up to mount the bowl assembly. Ensure the lock button is up.	_	Lock button is up.

2) Diaphragm assembly

Applicable model	Process	Procedure	Tools	Check item
	Disassembly	Remove the bonnet Rotate the set screw counterclockwise with cross pointed driver to remove the bonnet from the body.	Cross pointed driver	_
AWD20		Remove parts in order of the pressure adjusting screw assembly, pressure adjusting spring, and the diaphragm assembly. Please be noted that the diaphragm assembly adheres to the bonnet if disassemble parts with the handle facing downwards	_	_
AWD20 AWD30 AWD40	Assembly	3) Mount parts to the body in order of the diaphragm assembly, pressure adjusting spring, and pressure adjusting screw. Mind the direction of the diaphragm assembly and pressure adjusting screw assembly. See attached disassembly drawing.	_	Direction of pressure adjusting screw assembly and diaphragm assembly
		4) Mount the bonnet to the body Mount the convex of the bonnet comes INside to the body, and settle it roughly with four(4) set screws with a cross pointed driver. Then, Tighten screws diagonally with the tightening torque in the check item to settle.	Cross pointed driver	Tightening torque AWD20 2.15±0.3N⋅m AWD30 2.35±0.3N⋅m AWD40 3.5±0.3N⋅m

3) Valve assembly

Applicable model	Process		Procedure	Tools	Check item
	Disassembly	1)	Remove element after removing bowl assembly.	Spanner	
			Hold the element with a spanner to rotate it	Nominal:7	_
			counterclockwise and remove the element.		
		2)	Hold the valve guide with a socket wrench to rotate it	Socket wrench	_
			counterclockwise and remove the valve guide.	Nominal:18	
		3)	Remove the valve spring.	1	_
		4)	Remove the valve.	_	_
	Assembly	5)	Mount the valve .		Positioning the stem
			Mate the stem convex and the valve assembly center	_	and the valve(centering)
			hole.		and the valve(contenting)
		6)	Mount the valve spring.	_	_
			Insert the valve spring to the valve hole.		
AWD20		7)	Mount the valve guide.		
			Hold the valve guide with a socket wrench to rotate it	Socket wrench	Tightening torque:
			clockwise and mount the valve guide. See check item	Nominal:18	40±3.5N•m
			for the tightening torque.		
		8)	Mount the element.	•	
			Hold the element with a spanner to rotate it	Spanner	Tightening torque:
			clockwise and remove the element. See check item	Nominal:7	0.35±0.05N•m
		0)	for the tightening torque.		
		9)	Mount the bolw assembly. Hold the bowl assembly by hand and rotate clockwise.		Refential tightening torque:
			Do not use tool for mounting because the bowl may	_	2.2N•m
			be damaged. See check item for referential tightening		2.211-111
			torque.		
	Disassembly	1)	Remove element after removing bowl assembly.		
		.,	Hold the element with a round pliers to rotate it	.	
			counterclockwise and remove the element.	Round pliers	_
		2)	Hold the valve guide with a spanner to rotate it	Spanner nominal	
			counterclockwise and remove the valve guide.	AWD30 8	_
				AWD40 12	
		3)	Remove the valve spring.	_	_
	A a a a a a a la la c	4)	Remove the valve. Mount the valve .		
	Assembly	3)	Mount the valve . Mate the stem convex and the valve assembly center	_	Positioning the stem
			hole.	_ _	and the valve(centering)
		6)	Mount the valve spring.		
		5,	Insert the valve spring. Insert the valve spring to the valve hole.	_	_
AWD30		7)	Mount the valve guide.	Spanner nominal	Tightening torque
AWD40		- /	Hold the valve guide with a spanner to rotate it	AWD30 8	AWD30 25±2.5N•m
			clockwise and mount the valve guide. See check item	AWD40 12	AWD40 55± 5N·m
			for the tightening torque.		
		8)	Mount the element.		
			Hold the element with a round pliers to rotate it	والمالية المالية	Tightening torque:
			clockwise and mount the element. See check item for	Round pliers	0.35±0.05N•m
			the tightening torque.		
		9)	Mount the bolw assembly.		
			Match the mating mark of the body and the bowl		
			assembly to insert the assembly to the body. Rotate	_	Lock button is up.
			the assembly 45 degree(right or left) until the lock		Look Baccoll 13 up.
			button is tossed up to mount the bowl assembly.		
			Ensure the lock button is up.		

4) Bracket assembly/panel mount

Applicable model	Process	Procedure	Tools	Check item
	Assembly	Mount the parts to the bracket(panel) Mate the bracket(panel) concave and the bonnet convex to mount the bracket.	1	_
AWD20 AWD30 AWD40		2) Settle the bracket(panel) with set nut. Rotate the set nut clockwise with a hook spanner to settle the parts to the bracket(panel). See check item for tightening torque. Set nut roulette faces shall face the bracket. When mounting with bracket, set nut tightened manually is adequate fir general used.	AWM20/30/40 Hook spanner Nominal AWD20 34/38 AWD30 52/55 AWD40 52/55	Tightening torque AWD20 2.0±0.2N⋅m AWD30 3.5±0.3N⋅m AWD40 4.0±0.4N⋅m

5)Square embedded pressure gauge

Applicable model	Process		Procedure	Tools	Check item
	Disassembly	1)	Remove the pressure gauge cover Rotate the pressure gauge cover 15 degree counterclockwise to pull out the pressure gauge cover.	_	-
			Remove the pressure gauge Rotate two set screws counterclockwise with cross pointed driver to remove the pressure gauge and two set screws.	Cross pointed driver	
AWD20 AWD30	Assembly	3)	Ensure "O" ring is mounted to the pressure gauge Mount "O" ring to the pressure gauge if the ring fall off.	1	Presence of "O" ring
AWD40		4)	Mount the pressure gauge Rotate two set screws clockwise with cross pointed driver to set screws temporary. Then settle them with tightening torque in check item.	Cross pointed driver	Tightening torque: 0.3±0.05N•m
		5)	Mount the pressure gauge cover Insert the pressure gauge mating two detent of the pressure gauge and holes for them so that the arrow of the pressure gauge cover comes upper right. Rotate the pressure gauge cover 15 degree opposite to the arrow to mount the pressure gauge.	_	_

6)Circular pressure gauge

Applicable model	Process	Procedure	Tools	Check item			
	Disassembly	Remove the pressure gauge Hold the pressure gauge with a spanner on the spanner flat. Then, rotate the gauge counterclockwise to remove the gauge.	Spanner Nominal :	_			
AWD20 AWD30 AWD40	Assembly	2) Rap the pressure gauge thread with the seal tape leaving 1.5 to 2 threads from the end.	_	Wrap seal tape leaving 1.5 to 2 threads			
		Mount the pressure gauge Hold the pressure gauge on the spanner flat with a spanner, and rotate it clockwise to mount the circular pressure gauge. See Check item for tightening torque of pressure gauge.	Spanner Nominal: AWD20 AWD30 AWD40 12	Tightening torque: AWD20 AWD30 7~9 N·m AWD40 12~14 N·m			

7)Pressure gauge adapter, Plug assembly


Applicable model	Process		Procedure	Tools	Check item			
	Disassembly	1)	Remove the plug Insert the hexagon spanner to hexagon hole of hexagon plug. Rotate the plug counterclockwise to remove the plug.	Spanner Nominal :				
AWD20		2)	Remove the pressure gauge adapter Rotate two set screws counterclockwise with cross pointed driver to remove the pressure gauge and two set screws.	Cross pointed driver	_			
AWD30	Assembly	3)	Confirm pressure gauge adapter has "O" ring. If not, mount "O" ring.	-	_			
AWD40		4)	Mount pressure gauge adapter. Rotate two screws clockwise by Phillips driver to fix pressure gauge adapter. See Check item for tightening torque of two screws.	Cross pointed driver (Torque driver)	Tightening torque: 0.3±0.05N•m			
		5)	Mount plug assembly. Insert hexagon spanner into hexagon hole on the plug and rotate clockwise to fix the plug. See Check item for tightening torque of two screws.	Spanner Nominal :	Tightening torque: AWD20 0.6 ± 0.05 N⋅m AWD30 1.0 ± 0.1 N⋅m			

8)Blanking plate

Applicable model	Process	Procedure	Tools	Check item
	Disassembly	 Rotate two set screws counterclockwise with cross pointed driver to remove the blanking plate and two set screws. 	Cross pointed driver	I
AWD20 AWD30 AWD40	Assembly	2) Remove the pressure gauge adapter Confirm blanking plate has "O" ring. If not, mount "O" ring.	1	ı
AWD40		Mount the blanking plate. Rotate two screws clockwise by Phillips driver to fix blanking plate. See Check item for tightening torque of two screws.	Cross pointed driver (Torque driver)	Tightening torque: 0.3±0.05N•m


10. DISASSEMBLY DRAWING

1) AWD20 Disassembly drawing.




Note.) It is possible to mount (I)Square embedded pressure gauge or (I)Pressure gauge adaptor assembly or (I)Plug assembly instead of (I)Blanking plate assembly.

2) AWD30/40 Disassembly drawing.




Note.) It is possible to mount 1Square embedded pressure gauge or 3Pressure gauge adaptor assembly or 4Plug assembly instead of 6Blanking plate assembly.

3)AWD20/30/40 Bracket assembly Panel mounting Disassembly drawing.



11. DIMENSIONS



Dimensions

Dimensions																				
Model		Gauge port size	Standard							Accessory										
	Port size									Pressure gauge			Bracket mounting dimensions							
			Α	B ^{(Note1}	С	D	Е	F	G	Н	К	М	N	Р	Q	S	Т	U		
AWD20	1/8•1/4	1/8	40	173	73	52	_	45	37.5	63	5	30	34	44	5.4	15.4	55	2.3		
AWD30	1/4•3/8	1/8	53	201	86	59	57	50	37.5	66	3.5	41	40	46	6.5	8	53	2.3		
AWD40	1/4:3/8:1/2	1/4	70	239	92	75	73	70	42.5	76	1.5	50	54	54	8.5	10.5	70	2.3		

	Accessory											
Model		Panel mounting										
	٧	W	Υ	Z	AA							
AWD20	30	28.5	14	6	M28 × 1							
AWD30	31	38.5	19	7	M38 × 1.5							
AWD40	35.5	42.5	21	7	M42 × 1.5							

B for Auto-drain / Optional bowl assembly

2 for Alato aram, optional both accombly																							
Accessory	-												С						D				
Model Option	2	6	8	С	6C	J	2J	6J	8J	CJ	6CJ	W	6W	-	2	6	8	С	6C	-	2	6	8
AWD20	173	173	-	173	173	177	180	177	-	177	177	_	_	190	190	190	_	190	190	_	_	_	_
AWD30	214	201	234	_	_	208	208	208	228	_	_	209	209	242	242	242	242	_	_	242	242	242	242
AWD40	251	239	272	_	_	246	246	246	266	_	_	247	247	278	280	278	280	_	_	278	280	278	280

Note 1) The specifications of auto-drain and optional bowl assembly are described in \(\Gamma \). SPECIFICATIONS OF BOWL ASSEMBLY \(\Gamma \) (P10\(\sigma \)P12).

Revision history A The tightening torque value of the element assy is changed. 2017.7

SMC Corporation

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021 JAPAN Tel: + 81 3 5207 8249 Fax: +81 3 5298 5362

URL http://www.smcworld.com

