

# Clamp Cylinder

ø40, ø50, ø63

New  
RoHS

Weight **7%** reduction

1.96 kg ▶ 1.82 kg

Compared with the existing CK1 series model, ø63, 150 mm stroke




3 types of clevis widths

**12.5 mm** **16.5 mm** **19.5 mm**


Possible to select depending on the application

Mounting dimensions are interchangeable with the existing CK1 series model.



**CK□1 Series**


## Switch mounting rod and piping port are mountable in three orientations.



## Various types of auto switches can be mounted.

### Magnetic field resistant auto switches


D-P3DWA, D-P4DW,  
D-P79WSE, D-P74□



### Standard auto switches


D-M9□W, D-A9□



	Series		Bore size [mm]			Stroke [mm]	Clevis width [mm]	Page
			40	50	63			
	Standard magnet type	<b>CKG1□-Z1</b>	●	●	●	50, 75, 100, 125, 150, 200*1 *1 Excludes ø40	12.5 16.5 19.5	3
	Without magnet	<b>CK1□-Z1</b>	●	●	●			
	Strong magnet type	<b>CKP1□-Z1</b>	●	●	●			5

# CONTENTS

## Clamp Cylinder **CK□1 Series**



### ■ **Clamp Cylinder CK1/CKG1 Series**

How to Order .....	p. 3
--------------------	------

### ■ **Clamp Cylinder/Strong Magnet Type CKP1 Series**


How to Order .....	p. 5
Specifications .....	p. 6
Weight .....	p. 6
Construction .....	p. 7
Dimensions .....	p. 8
End Brackets .....	p. 9
Options .....	p. 10
Auto Switch Mounting (Rod Mounting Type) .....	p. 11
Auto Switch Mounting (Band Mounting Type) .....	p. 13
Auto Switch Mounting .....	p. 15
Prior to Use: Auto Switch Connections and Examples .....	p. 16
Specific Product Precautions .....	p. 17

# Clamp Cylinder

# CK1/CKG1 Series

∅40, ∅50, ∅63

RoHS



## How to Order

### Without auto switch

CK1 A 50 [ ] - 100 Y [ ] Z1

### With magnetic field resistant auto switch\*1

CKG1 A 50 [ ] - 100 Y [ ] Z1 - P3DWASC [ ]

\*1 Refer to page 15 when band-mounting the D-P4DW□ type auto switch.

### With standard auto switch

CKG1 A 50 [ ] - 100 Y [ ] Z1 - M9BW [ ] - [ ]

### Built-in standard magnet for auto switch

#### 1 Clevis width

A	16.5 mm
B	19.5 mm
C	12.5 mm

#### 2 Bore size

40	40 mm
50	50 mm
63	63 mm

#### 3 Thread type

Nil	Rc1/4
TN	NPT1/4
TF	G1/4

#### 4 Cylinder stroke [mm]

40	50, 75, 100, 125, 150
50	50, 75, 100, 125, 150, 200
63	50, 75, 100, 125, 150, 200

\* Contact SMC when an intermediate stroke is necessary.

#### 5 End bracket

Nil	None
I	Single knuckle joint (M6 without tap)
IA	Single knuckle joint (M6 with tap)
Y	Double knuckle joint (M6 without tap)
YA	Double knuckle joint (M6 with tap)

\* A knuckle pin, cotter pins, and flat washers are provided as a standard for Y and YA.

#### 6 Option

Nil	None
B	Limit switch mounting base*1
D	Dog fitting*1
L	Foot bracket
K*2	Pedestal (for 75, 100, 150 mm strokes only)

\*1 Only IA or YA (M6 with tap) is selectable as the end bracket for the B, D, and BD types.

\*2 Only available for clevis width A (16.5 mm)

#### 7 Magnetic field resistant auto switch

\* Select applicable auto switch models from Table 1.

Nil	Without auto switch (Built-in magnet) Without switch mounting rod
P	Without auto switch (Built-in magnet) With switch mounting rod

#### 8 Standard auto switch

\* For applicable auto switches, refer to Table 2.

\* Auto switches are shipped together with the product but do not come assembled.

Nil	Without auto switch (Built-in magnet)
-----	---------------------------------------

#### 9 Number of auto switches

Nil	2
S	1
n	n

#### 10 Auto switch mounting type

Nil	Band mounting
P	Rod mounting

## Built-in Standard Magnet Cylinder Part No.

1) Built-in standard magnet without auto switch, without switch mounting rod

Symbol for the auto switch type is "Nil" as shown below.  
(Example) CKG1A50-50YZ1

2) Built-in standard magnet without auto switch, with switch mounting rod

Symbol for the auto switch type is "P" as shown below.  
(Example) CKG1A50-50YZ1-P

\* The auto switch mounting bracket is not included.

**Table 1. Magnetic Field Resistant Auto Switches**/Refer to the **Web Catalog** for detailed auto switch specifications.

Type	Rod mounting	Band mounting	Auto switch model	Applicable magnetic field	Electrical entry	Indicator light	Wiring (Pin no. in use)	Load voltage	Lead wire length	Applicable load
Solid state auto switch	●	—	D-P3DWASC	AC magnetic field (Single-phase AC welding magnetic field)	Pre-wired connector	2-color indicator	2-wire (3-4)	24 VDC	0.3 m	Relay, PLC
	●	—	D-P3DWASE				2-wire (1-4)		0.5 m	
	●	—	D-P3DWA		Grommet		2-wire		3 m	
	●	—	D-P3DWAL				2-wire		5 m	
	●	—	D-P3DWAZ		Pre-wired connector		2-wire (3-4)		0.3 m	
	●	●	D-P4DWSC				2-wire (1-4)		3 m	
	●	●	D-P4DWSE		Grommet		2-wire		5 m	
	●	●	D-P4DWL							
●	●	D-P4DWZ								

\* Refer to page 12 when ordering the auto switch mounting bracket or switch mounting rod assembly.

\* For the D-P3DWA□, the auto switch and auto switch mounting bracket are shipped together with the product but do not come assembled.

**Table 2. Standard Auto Switches** ⚠ Standard auto switches cannot be used under a strong magnetic field.

Type	Special function	Electrical entry	Indicator light	Wiring (Output)	Load voltage		Auto switch model	Lead wire length [m]				Pre-wired connector	Applicable load		
					DC	AC		0.5 (Nil)	1 (M)	3 (L)	5 (Z)				
Solid state auto switch	—	Grommet	Yes	3-wire (NPN)	24 V	5 V, 12 V	—	M9N	●	●	●	○	○	IC circuit	Relay, PLC
				3-wire (PNP)				M9P	●	●	●	○	○		
				2-wire	M9B	●		●	●	○	○	—			
				3-wire (NPN)	M9NW	●		●	●	○	○	IC circuit			
	Diagnostic indication (2-color indicator)			3-wire (PNP)	M9PW	●		●	●	○	○	—			
				2-wire	M9BW	●		●	●	○	○	—			
				Water resistant (2-color indicator)	3-wire (NPN)	M9NA		○	○	●	○	○	IC circuit		
					3-wire (PNP)	M9PA		○	○	●	○	○	—		
2-wire	M9BA	○	○	●	○	○	—								
	—	Grommet	Yes	3-wire (NPN equivalent)	—	5 V	—	A96	●	—	●	—	—	IC circuit	—
Reed auto switch	—			No	2-wire	24 V	12 V	100 V	A93	●	●	●	●	—	—
		5 V, 12 V	100 V or less				A90	●	—	●	—	—	IC circuit	—	


\* Solid state auto switches marked with a "○" are produced upon receipt of order

\* Auto switches and mounting brackets are shipped together with the product but do not come assembled.

\* For the standard magnet type (CKG1), auto switches other than those described above cannot be used.

\* Lead wire length symbols: 0.5 m.....Nil (Example) M9NWV  
 1 m.....M (Example) M9NWVM  
 3 m.....L (Example) M9NWVL  
 5 m.....Z (Example) M9NWVZ

# Clamp Cylinder Strong Magnet Type **CKP1 Series** Ø40, Ø50, Ø63



## How to Order

With magnetic field resistant auto switch **CKP1 A 50** - **100 Y** **Z1** - **P79WSE**

Built-in strong magnet for auto switch

<b>1</b> Clevis width	<b>2</b> Bore size	<b>3</b> Thread type	<b>4</b> Cylinder stroke [mm]
<b>A</b> 16.5 mm	<b>40</b> 40 mm	<b>Nil</b> Rc1/4	<b>40</b> 50, 75, 100, 125, 150
<b>B</b> 19.5 mm	<b>50</b> 50 mm	<b>TN</b> NPT1/4	<b>50</b> 50, 75, 100, 125, 150, 200
<b>C</b> 12.5 mm	<b>63</b> 63 mm	<b>TF</b> G1/4	<b>63</b> 50, 75, 100, 125, 150, 200

<b>5</b> End bracket
<b>Nil</b> None
<b>I</b> Single knuckle joint (M6 without tap)
<b>IA</b> Single knuckle joint (M6 with tap)
<b>Y</b> Double knuckle joint (M6 without tap)
<b>YA</b> Double knuckle joint (M6 with tap)

\* A knuckle pin, cotter pins, and flat washers are provided as a standard for Y and YA.

<b>6</b> Option
<b>Nil</b> None
<b>B</b> Limit switch mounting base*1
<b>D</b> Dog fitting*1
<b>L</b> Foot bracket
<b>K*2</b> Pedestal (for 75, 100, 150 mm strokes only)

\*1 Only IA or YA (M6 with tap) is selectable as the end bracket for the B, D, and BD types.  
\*2 Only available for clevis width A (16.5 mm)

<b>7</b> Auto switch
* Select applicable auto switch models from the table below.
<b>Nil</b> Without auto switch (Built-in magnet) Without switch mounting rod
<b>P</b> Without auto switch (Built-in magnet) With switch mounting rod

<b>8</b> Number of auto switches
<b>Nil</b> 2
<b>S</b> 1
<b>n</b> n

### Built-in Strong Magnet Cylinder Part No.

- Built-in strong magnet without auto switch, without switch mounting rod  
Symbol for the auto switch type is "Nil" as shown below.  
(Example) CKP1A50-50YZ1
- Built-in strong magnet without auto switch, with switch mounting rod  
Symbol for the auto switch type is "P" as shown below.  
(Example) CKP1A50-50YZ1-P  
\* The auto switch mounting bracket is not included.

### Magnetic Field Resistant Auto Switches/Refer to the Web Catalog for detailed auto switch specifications.

Type	Auto switch model	Applicable magnetic field	Electrical entry	Indicator light	Wiring (Pin no. in use)	Load voltage	Lead wire length	Applicable load
Reed auto switch	D-P79WSE	DC/AC magnetic field	Pre-wired connector	2-color indicator	2-wire (1-4)	24 VDC	0.3 m	Relay, PLC
	D-P74L		Grommet	1-color indicator	2-wire	24 VDC	3 m	
	D-P74Z					100 VAC	5 m	

\* Refer to page 12 when ordering the auto switch mounting bracket or switch mounting rod assembly.  
\* For the D-P79WSE and D-P74□, the auto switch and auto switch mounting bracket are shipped together with the product but do not come assembled.  
\* For the strong magnet type (CKP1), auto switches other than those described above cannot be used.







Refer to pages 11 to 15 for cylinders with auto switches.

- Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height
- Minimum Stroke for Auto Switch Mounting
- Operating Range
- Auto Switch Mounting Brackets/Part Nos.

## Specifications

Bore size [mm]	40	50	63
<b>Fluid</b>	Air		
<b>Proof pressure</b>	1.5 MPa		
<b>Max. operating pressure</b>	1.0 MPa		
<b>Min. operating pressure</b>	0.05 MPa		
<b>Ambient and fluid temperatures</b>	Without auto switch: -10 to 70°C With auto switch: -10 to 60°C		
<b>Piston speed</b>	50 to 500 mm/s		
<b>Cushion</b>	Unclamped side (head end): With air cushion		
<b>Speed controller</b>	Equipped on both ends		
<b>Lubrication</b>	Non-lube		
<b>Stroke length tolerance</b>	+1.4 0		
<b>Mounting*1</b>	Double clevis		

\*1 A clevis pin, cotter pins, and flat washers are equipped as a standard.

## End Brackets/Options

Symbol	Description	Part no.			
		CKG1A/CKP1A	CKG1B/CKP1B	CKG1C/CKP1C	
<b>I</b>	Single knuckle joint	M6 without tap	CKB-I04		
<b>IA</b>		M6 with tap	CKB-IA04		
<b>Y</b>	Double knuckle joint (A knuckle pin, cotter pins, and flat washers are equipped as a standard.)	M6 without tap	CKA-Y04	CKB-Y04	CKC-Y04
<b>YA</b>		M6 with tap	CKA-YA04	CKB-YA04	CKC-YA04

\* For details on dimensions, refer to pages 9 and 10.

## Cylinder Weight

Bore size [mm]		ø40	ø50	ø63
CK(G)1□ cylinder	Basic weight	0.74	0.86	1.04
	Additional weight per 25 mm of stroke	0.10	0.11	0.13
CKG1□ cylinder*1	Basic weight	0.75	0.87	1.05
	Additional weight per 25 mm of stroke*1	0.11	0.12	0.14
CKP1□ cylinder*1	Basic weight	0.83	0.97	1.19
	Additional weight per 25 mm of stroke*1	0.11	0.12	0.14

\*1 Weight including the auto switch mounting rod

## Option/Bracket Weight

Description	ø40/ø50/ø63	
Double knuckle joint	0.34	
Single knuckle joint	0.20	
Knuckle pin	0.06	
Foot bracket	0.23	
Limit switch mounting base	0.23	
Dog fitting	0.12	
Pedestal	75 mm stroke	2.01
	100 mm stroke	1.97
	150 mm stroke	1.99

\* Required accessories for mounting are included in each optional bracket.


## Theoretical Output

Bore size [mm]	Rod size [mm]	Operating direction	Piston area [mm <sup>2</sup> ]	Operating pressure [MPa]			
				0.3	0.4	0.5	0.6
40	20	OUT	1260	378	504	630	756
		IN	943	283	377	472	566
50	20	OUT	1960	588	784	980	1180
		IN	1650	495	660	825	990
63	20	OUT	3120	934	1250	1560	1870
		IN	2800	840	1120	1400	1680

# CK□1 Series

## Construction

### CKG1□40, 50, 63-□Z1




#### Component Parts

No.	Description	Material	Note
1	Rod cover	Aluminum die-casted	Chromating
2	Head cover	Aluminum alloy	Anodized
3	Cylinder tube	Aluminum alloy	Hard anodized
4	Piston	Aluminum alloy	
5	Piston rod	Carbon steel	Hard chrome plating
6	Bushing	Bearing alloy	
7	Cushion valve	Steel wire	Black zinc chromating
8	Speed controller valve	Steel wire	ø40: Electroless nickel plating ø50, ø63: Zinc chromating
9	Bushing	Oil-impregnated sintered alloy	
10	Hexagon socket head plug	Carbon steel	
11	Pin	Carbon steel	
12	Cotter pin	Steel wire	

No.	Description	Material	Note
13	Flat washer	Steel wire	
14	Wear ring	Resin	
15	Cushion seal	Urethane	
16	Cushion valve seal	NBR	
17	Speed controller valve seal	NBR	
18	Coil scraper	Phosphor bronze	
19	Rod seal	NBR	
20	Piston seal	NBR	
21	Cylinder tube gasket	NBR	
22	Cushion ring	Aluminum alloy	Anodized
23	Spacer	Bearing alloy	
24	Magnet	—	

### CKP1□40, 50, 63-□Z1



#### Component Parts

No.	Description	Material	Note
1	Rod cover	Aluminum die-casted	Chromating
2	Head cover	Aluminum alloy	Anodized
3	Cylinder tube	Aluminum alloy	Hard anodized
4	Piston	Aluminum alloy	
5	Piston rod	Carbon steel	Hard chrome plating
6	Bushing	Bearing alloy	
7	Cushion valve	Steel wire	Black zinc chromating
8	Speed controller valve	Steel wire	ø40: Electroless nickel plating ø50, ø63: Zinc chromating
9	Bushing	Oil-impregnated sintered alloy	
10	Hexagon socket head plug	Carbon steel	
11	Pin	Carbon steel	
12	Cotter pin	Steel wire	
13	Flat washer	Steel wire	
14	Wear ring	Resin	
15	Cushion seal	Urethane	
16	Cushion valve seal	NBR	
17	Speed controller valve seal	NBR	

No.	Description	Material	Note
18	Coil scraper	Phosphor bronze	
19	Rod seal	NBR	
20	Piston seal	NBR	
21	Cylinder tube gasket	NBR	
22	Magnet holder	Aluminum alloy	
23	Magnet	—	
24	Switch mounting rod	Steel	
25	Switch mounting bracket	Aluminum alloy	
26	Magnetic field resistant auto switch	—	
27	Hexagon socket head cap screw	Steel	M4 x 0.7 x 14 L
28	Hexagon socket head cap screw	Steel	M4 x 0.7 x 8 L 2 pcs. per switch
29	Hexagon socket head cap screw	Steel	M3 x 0.5 x 16 L 2 pcs. per switch
30	Switch mounting spacer	Aluminum alloy	
31	Cushion ring	Aluminum alloy	Anodized
32	Spacer	Bearing alloy	

#### Replacement Parts/Seal Kit (CK□1 common)

Bore size [mm]	Order no.	Contents
40	CK1A40-PS	Set of nos. (19, 20, 21)

\* The seal kit does not include a grease pack. Order it separately.


**Grease pack part no.: GR-S-010** (compatible with all sizes)

\* Cylinders with ø50 or larger bore sizes are tightened with a large tightening torque and cannot be disassembled. If disassembly is required, please contact SMC.



## Dimensions

### CK□1□40, 50, 63-□Z1




Unit: mm

Bore size	Symbol	F	φIA	φIB	N	S	W	θ°	P		
									Nil	TN	TF
40		44	52	47	52	53	5	23	Rc1/4	NPT1/4	G1/4
50		55	60	58	49	56	4.5	21			
63		69	74	72	49	56	4.5	19			

\*1 Indicates the point where the clevis is narrowest (on the tube side)

\*2 Indicates the range applicable to the clevis width

### CKP1□40, 50, 63-□Z1



Unit: mm

Bore size	Symbol	F	φIA	φIB	N	S	W	Z	ZZ	Hs	θ°	P		
												Nil	TN	TF
40		44	52	47	52	58	5	83	195	47.5	23	Rc1/4	NPT1/4	G1/4
50		55	60	58	49	58	4.5	80	192	51	21			
63		69	74	72	49	58	4.5	80	192	57.5	19			

\*1 Indicates the point where the clevis is narrowest (on the tube side)

\*2 Indicates the range applicable to the clevis width






# CK□1 Series


# Auto Switch Mounting (Rod Mounting Type)

## Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

### D-P3DWA□




### D-P4DW□



\* The above drawing is the switch rod mounting example for the D-P4DWS□.

### D-P79WSE


### D-P74□



\* The above drawing is the switch rod mounting example for the D-P79WSE.

### D-M9□/M9□W

### D-M9□A/A9□



### CKG1 (Standard magnet type)

Unit: mm

Auto switch model	Symbol	Auto switch set value and mounting height		
		ø40	ø50	ø63
D-P3DWA□	A	6.5	8	8
	B	25.5	27	27
	Hs	46.5	52	59
D-P4DW□	A	4	5.5	5.5
	B	23	24.5	24.5
	Hs	45.5	51	58.5
D-M9□ D-M9□W D-M9□A	A	11	12.5	12.5
	B	30	31.5	31.5
	Hs	39	44.5	51.5
D-A9□	A	7	8.5	8.5
	B	26	27.5	27.5
	Hs	39	44.5	51.5

### CKP1 (Strong magnet type)

Unit: mm

Auto switch model	Symbol	Auto switch set value and mounting height		
		ø40	ø50	ø63
D-P79WSE D-P74□	A	0	0	0
	B	21.5	26	26
	Hs	47.5	51	57.5

\* The mounting position should be referred for reference only for the auto switch mounting position at the stroke end detection. Adjust the auto switch after confirming the operation to set actually.

\* In the case of a 2-color indicator auto switch, mount it at the center of the green LED illuminating range.

However, pay attention that for D-P79WSE the green indicator light will not be illuminated when used close to the edge of the rod end.

\* Adjust the auto switch after confirming the operating conditions in the actual setting.

## Minimum Stroke for Auto Switch Mounting

Unit: mm

Auto switch model	With 1 pc.	With 2 pcs.	
		Different surfaces	Same surface
D-P3DWA□	50	50	50
D-P4DW□			
D-P79WSE			
D-P74□			

\* When two D-P3DWA□ are mounted to the cylinder with stroke 50 mm, mount them on different surfaces.

\* The standard strokes of CKG1 are 50, 75, 100, 125, and 150 mm. The values in the table above are not based on the minimum detection interval when setting the D-P3DWA auto switch, but on the standard minimum stroke of the cylinder.


## Operating Range

Unit: mm

Auto switch model	Bore size		
	40	50	63
D-P3DWA□	5.5	5.5	5.5
D-P4DW□	4	4	4.5
D-P79WSE	8	9	9.5
D-P74□			
D-M9□ D-M9□W D-M9□A	4	4.5	5
D-A9□	8	8	9


\* Values which include hysteresis are for reference purposes only. They are not a guarantee (assuming approximately ±30% dispersion) and may change substantially depending on the ambient environment.

## Auto Switch Mounting Brackets/Part Nos.



**D-P4DW□**  
**D-P79W□\*1**  
**D-P74**

Hexagon socket head cap screw  
 (M3 tightening torque: 0.5 to 0.7 N-m)



\*1 For the D-P79W□, face the soft-resin mold surface to the switch mounting bracket side for mounting.

### Auto Switch Mounting Rod Assembly/Part Nos. CKG1 Series



Bore size [mm]	Cylinder stroke [mm]	Part no.
40	50	CKG40-RZ050A
	75	CKG40-RZ075A
	100	CKG40-RZ100A
	125	CKG40-RZ125A
	150	CKG40-RZ150A
50, 63	50	CKG50-RZ050A
	75	CKG50-RZ075A
	100	CKG50-RZ100A
	125	CKG50-RZ125A
	150	CKG50-RZ150A
	200	CKG50-RZ200A

### CKP1 Series

Bore size [mm]	Cylinder stroke [mm]	Part no.
40	50	CKP50-RZ050A
	75	CKP50-RZ075A
	100	CKP50-RZ100A
	125	CKP50-RZ125A
	150	CKP50-RZ150A
50, 63	50	CKP50-RZ050A
	75	CKP50-RZ075A
	100	CKP50-RZ100A
	125	CKP50-RZ125A
	150	CKP50-RZ150A
	200	CKP50-RZ200A

**D-M9□/M9□W**  
**D-M9□A/A9□**

Hexagon socket head set screw (M4 x 11 L)  
 (Tightening torque: 1.0 to 1.2 N-m)



\*2 Mount the part E of the auto switch mounting bracket so that it is in contact with the cylinder tube.

\* The tightening torque for the hexagon socket head cap screw A (M2.5) is 0.2 to 0.3 N-m. Hold the shorter side of a hexagon wrench, and turn it to tighten. (Too much tightening may break the switch.)

\* Tighten the hexagon socket head cap screws B and C (M4) with a tightening torque of 1 to 1.2 N-m.

### Auto Switch Mounting Brackets/Part Nos.


Applicable cylinder	Applicable auto switch	Part no.		
		ø40	ø50	ø63
CKG1	D-P3DWA□		BK7-040S	
	D-P4DW□		BK1T-040	
	D-M9□ D-A9□		BA7-040	
CKP1	D-P79WSE D-P74L/Z		BAP1T-040	

# CK□1 Series

# Auto Switch Mounting (Band Mounting Type)


## Auto Switch Proper Mounting Position (Detection at stroke end) and Mounting Height

### D-P4DW□



\* The above drawing is the switch band mounting example for the D-P4DWS□.

### D-M9□/M9□W D-M9□A/A9□



## ⚠ Caution

As for the precautions on the auto switches, product specifications, refer to pages 17 and 18.

## Operating Range

Unit: mm

Auto switch model	Bore size		
	40	50	63
D-P4DW□	5	5	5.5
D-M9□ D-M9□W D-M9□A	5.5	6.5	7
D-A9□	8	8	9

\* Values which include hysteresis are for reference purposes only. They are not a guarantee (assuming approximately ±30% dispersion) and may change substantially depending on the ambient environment.

### CKG1 (Standard magnet type)

Unit: mm

Auto switch model	Symbol	Auto switch set value and mounting height		
		ø40	ø50	ø63
D-P4DW□	A	4	5.5	5.5
	B	23	24.5	24.5
	Hs	43	48	55
	Ht	46	51.5	58.5
	θ	40	36	33
D-M9□ D-M9□W D-M9□A	A	11	12.5	12.5
	B	30	31.5	31.5
	Hs	35	40.5	47.5
D-A9□	A	7	8.5	8.5
	B	26	27.5	27.5
	Hs	35	40.5	47.5

\* The mounting position should be referred for reference only for the auto switch mounting position at the stroke end detection. Adjust the auto switch after confirming the operation to set actually.

\* The auto switch mounting position is temporarily set at the time of shipping from our factory. Change it to the desired position in accordance to your facility.

\* For the D-M9□/M9□W/M9□A/A9□, A and B are the dimensions from the end of the head cover/rod cover to the end of the auto switch.

\* As for the D-P4DW□ type, band mounting type, the auto switch mounting bracket and the auto switch have to be ordered separately. For details, refer to page 15.

\* In the case of a 2-color indicator auto switch, mount it at the center of the green LED illuminating range.

### Minimum Stroke for Auto Switch Mounting

Unit: mm

Auto switch model	With 1 pc.	With 2 pcs.	
		Different surfaces	Same surface
D-P4DW□	50	50	50
D-M9□ D-M9□W D-M9□A			
D-A9□			



## Auto Switch Mounting Brackets/Part Nos.

Auto switch model	Bore size [mm]		
	40	50	63
<b>D-P4DW□</b>	BA8-040	BA8-050	BA8-063

Auto switch model	Bore size [mm]		
	40	50	63
<b>D-M9□ D-M9□W D-A9□</b>	BMA3-040*1 (A set of a, b, c, d)	BMA3-050*1 (A set of a, b, c, d)	BMA3-063*1 (A set of a, b, c, d)
<b>D-M9□A*2</b>	BMA3-040S (A set of b, c, e, f)	BMA3-050S (A set of b, c, e, f)	BMA3-063S (A set of b, c, e, f)

(With switch installed)

\*1 Since the switch bracket (made of nylon) is affected in an environment where alcohol, chloroform, methylamines, hydrochloric acid, or sulfuric acid is splashed over, so it cannot be used. Please contact SMC regarding other chemicals.

\*2 When mounting a D-M9□A(V) type auto switch, if the switch bracket is mounted on the indicator light, it may damage the auto switch. Therefore, be sure to avoid mounting the switch bracket on the indicator light.

# CKG1 Series Auto Switch Mounting

## Magnetic Field Resistant Auto Switch D-P4DW□/Band Mounting Compliant

Band mounting of the magnetic field resistant auto switch (D-P4DW□) to the CKG1□ series is possible by ordering the switch mounting bracket and the auto switch individually.

### How to Order

Please order the switch mounting bracket, auto switch, and clamp cylinder individually. Refer to the table below for auto switch mounting bracket part numbers.

Part no.	Applicable auto switch model	Applicable clamp cylinder
BA8-040	D-P4DWSC	<b>CKG1□40</b>
BA8-050	D-P4DWSE	<b>CKG1□50</b>
BA8-063	D-P4DWL/Z	<b>CKG1□63</b>

### Ordering Example

Example case ① Cylinder: CKG1A50-50YZ1 ..... 1

Example case ② Magnetic field resistant auto switch:  
D-P4DWSC ..... 2

Example case ③ Switch mounting bracket: BA8-050 ..... 2

\* Please order the same quantity for the switch mounting bracket and the magnetic field resistant auto switch respectively.

\* Band mounting for the magnetic field resistant auto switches D-P79WS□, D-P74□ is not applicable.

### Applicable Magnetic Field Resistant Auto Switches/Refer to the **Web Catalog** for detailed auto switch specifications.


Applicable cylinder	Type	Auto switch model	Applicable magnetic field	Electrical entry	Indicator light	Wiring (Pin no. in use)	Load voltage	Lead wire length	Applicable load
CKG1	Solid state auto switch	P4DWSC	AC magnetic field (Single-phase AC welding magnetic field)	Pre-wired connector	2-color indicator	2-wire (3-4)	24 VDC	0.3 m	Relay, PLC
		P4DWSE				2-wire (1-4)		3 m	
		P4DWL		Grommet		2-wire		5 m	
		P4DWZ							

# Prior to Use


## Auto Switch Connections and Examples

### Sink Input Specifications

#### 3-wire, NPN




#### 2-wire




### Source Input Specifications

#### 3-wire, PNP



#### 2-wire




Connect according to the applicable PLC input specifications, as the connection method will vary depending on the PLC input specifications.


### Examples of AND (Series) and OR (Parallel) Connections

\* When using solid state auto switches, ensure the application is set up so the signals for the first 50 ms are invalid. Depending on the operating environment, the product may not operate properly.


#### 3-wire AND connection for NPN output (Using relays)




#### (Performed with auto switches only)




#### 3-wire OR connection for NPN output




#### 3-wire AND connection for PNP output (Using relays)




#### (Performed with auto switches only)



#### 3-wire OR connection for PNP output




#### 2-wire AND connection



When two auto switches are connected in series, a load may malfunction because the load voltage will decline when in the ON state. The indicator lights will light up when both of the auto switches are in the ON state. Auto switches with a load voltage less than 20 V cannot be used. Please contact SMC if using AND connection for a heat-resistant solid state auto switch or a trimmer switch.

Example) Load voltage at ON  
 Power supply voltage: 24 VDC  
 Internal voltage drop: 4 V  
 Load voltage at ON = Power supply voltage –  
 Internal voltage drop x 2 pcs.  
 = 24 V – 4 V x 2 pcs.  
 = 16 V

#### 2-wire OR connection



(Solid state)  
 When two auto switches are connected in parallel, malfunction may occur because the load voltage will increase when in the OFF state.

(Reed)  
 Because there is no current leakage, the load voltage will not increase when turned OFF. However, depending on the number of auto switches in the ON state, the indicator lights may sometimes grow dim or not light up, due to the dispersion and reduction of the current flowing to the auto switches.

Example) Load voltage at OFF  
 Leakage current: 1 mA  
 Load impedance: 3 kΩ  
 Load voltage at OFF = Leakage current x 2 pcs. x  
 Load impedance  
 = 1 mA x 2 pcs. x 3 kΩ  
 = 6 V











# CK□1 Series

## Specific Product Precautions 2







Be sure to read this before handling the products. Refer to the back cover for safety instructions. For actuator and auto switch precautions, refer to the “Handling Precautions for SMC Products” and the “Operation Manual” on the SMC website: <https://www.smcworld.com>

### Data: Magnetic Field Resistant Reed Auto Switches (D-P79WSE, D-P74□) Safety Distance

#### Safety Distance from Side of Auto Switch





#### Safety Distance from Top of Auto Switch




## Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of “**Caution**,” “**Warning**” or “**Danger**.” They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)\*1), and other safety regulations.

 **Caution:** **Caution** indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.

 **Warning:** **Warning** indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

 **Danger :** **Danger** indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

\*1) ISO 4414: Pneumatic fluid power – General rules relating to systems.  
ISO 4413: Hydraulic fluid power – General rules relating to systems.  
IEC 60204-1: Safety of machinery – Electrical equipment of machines.  
(Part 1: General requirements)  
ISO 10218-1: Manipulating industrial robots – Safety.  
etc.

### Warning

#### 1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

#### 2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

#### 3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.

1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

#### 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

### Caution

#### 1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.  
If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.  
If anything is unclear, contact your nearest sales branch.

### Limited warranty and Disclaimer/ Compliance Requirements

The product used is subject to the following “Limited warranty and Disclaimer” and “Compliance Requirements”.

Read and accept them before using the product.

#### Limited warranty and Disclaimer

1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.\*2)  
Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided.  
This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.

##### \*2) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.  
Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

#### Compliance Requirements

1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

### Caution

#### SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country. Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

## Safety Instructions

Be sure to read the “Handling Precautions for SMC Products” (M-E03-3) and “Operation Manual” before use.

## SMC Corporation

Akihabara UDX 15F,  
4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021, JAPAN  
Phone: 03-5207-8249 Fax: 03-5298-5362  
<https://www.smcworld.com>  
© 2022 SMC Corporation All Rights Reserved

Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.

D-G