Fieldbus System (For Input/Output)

EX600 Series

Supports digital inputs/outputs, analog inputs/outputs, and IO-Link units





② IO-Link unit compatible SI unit: PROFINET EtherNet/IP™ (Made to order)

<Compatible Protocols>

20000

PROFU® BUST DeviceNet CC-Link 10-Link

CC-LINK •

Nett

EtherNet/IP EtherCAT.

Made to order

Modbus POWERLINK CC-LINK IE Bield

Please contact SMC for details on compatible products.

IO-Link unit

- 2 models (port class A and port class B)
- Diagnosis is possible from the upper level communication.
- The data can be accessed from via PC (setting tool).
- Device parameter setting function, Automatic saving/writing
 For the integrated SI unit, only PROFINET or EtherNet/IP™ can be selected.
- PROFINET III to 3 IO I into write and discount for extremely in the selected
- PROFINET: Up to 9 IO-Link unit modules can be connected.
- EtherNet/IP™: Up to 4 IO-Link unit modules can be connected. (Made to order)


Self-diagnosis function

Equipped with an input/output open/shortcircuit detection function and an input/output signal ON/OFF counter function

Web server function*1

Status checks and forced output are possible via web browser.

Parameter setting is only for EtherNet/IP™.



The following connectors are selectable for the input/output devices: M12 connectors, M8 connectors, D-sub connectors, and spring type terminal blocks.


Up to 9 units*1 can be connected.


Up to 9 units can be connected in any order.

*1 Excludes SI units




Can be connected with digital, analog, and IO-Link units





■ Connectable Solenoid Valve/Vacuum Unit



Valve SI unit

| | | | VQC5000 | 17 | 0.31 | | 0.4 (Low-wallage type) | Ø180 |
|------|-------------------|--------|---------|---------------------|------|--------------------------|------------------------|----------------------------|
| | Applicable vacuun | n unit | | Nozzle diam [mm] | eter | Max. number of solenoids | Power consumption [W] | Max. vacuum pressure [kPa] |
| IP40 | | | | 0.7 | | | | |
| | CE CA ZI | (C UK | ZKO□A | 1.0 | | 16 | 0.4 | 0.1 |
| | | ZNZUA | 1.2 | | 10 | 0.4 | -91 | |
| | | | | 1.5 | | | | |

^{*1} Units with a D-sub communication connector are IP40.

^{*2} There is no manifold part number setting for the EX600-SPN3/4. (Order it separately.)

^{*3} The JSY1000 is IP40.

IO-Link

IO-Link is a communication technology for sensors and actuators that is an international standard, IEC 61131-9.

This technology is used to send/receive device information such as manufacturer, product part number, parameters, and diagnostic data, as well as the control data including ON/OFF signals and measured values of the sensor, by connecting the IO-Link master and device in a 1:1 configuration.

IO-Link enables condition monitoring and error detection of the sensor and equipment, and it can contribute to the reduction of startup labor and recovery time and the realization of preventive and predictive maintenance.

Reduced design and startup labor


- Batch setting of device parameters from the upper level
- Remote check of device information
- Detection and remote unified check of device misconnection/non-connection

Minimum recovery time due to error detection


- Early detection of location where problem is occurring via communication
- Early obtaining of information on problem phenomenon via communication
- Early recovery during product replacement (automatic setting of device parameters)

Preventive and predictive maintenance through condition monitoring

- Monitors changes in measured values of a sensor during signal ON/OFF
- Monitors the number of device operations and automatically notifies when the set number of operations has been exceeded
- Remote monitoring of device and equipment conditions via communication



IO-Link System Configuration



10-Link unit

 Acts as a gateway between the IO-Link communication and the upper level communication

10-Link device

 A sensor/actuator connecting to each port of the IO-Link unit in a 1:1 configuration

3 IODD file

- A file in which device properties and parameters are described
- · Registered to the setting tool
- Provided by the device manufacturer

4 Communication cable


- A 4-wire or 5-wire general-purpose cable that is the same as the existing sensor cable (Unshielded cable)
- Max. cable length: 20 m

IO-Link setting tool software

- Software for the setting and monitoring of an IO-Link unit/device
- *1 A setting tool compatible with the IO-Link units of every manufacturer is used for the SMC EX600 series IO-Link unit. (IO-Link Device Tool V5 manufactured by TMG Technologie und Engineering, Germany)


IO-Link Interface

The connecting part between the IO-Link unit and the device is called a "port." Each port can be switched between "IO-Link mode" for digital communication and "standard I/O mode" for conventional contact input/output.




■2 types of interfaces

There are two methods for power supply: one is for sensors, and the other is for actuators.



The control power supply wire and signal wire can be connected with one cable. (Mainly for sensors)



The control power supply wire, external power supply wire, and signal wire can be connected with one cable. (Mainly for actuators)




IO-Link Unit

■ Can be connected with digital, analog, and IO-Link unit units

PROFINET: Up to 9 IO-Link units can be connected. (Total of 36 ports)

EtherNet/IP™: Up to 4 IO-Link units can be connected. (Total of 16 ports)

Digital units, analog units, and IO-Link units can be mixed, and up to 9 units can be connected in any order.



■ Supports both port class A and port class B




For connecting IO-Link sensors


Pressure sensors, flow sensors, actuator position sensors, electro-pneumatic regulators, etc.



For connecting IO-Link compatible SI units (for valve driving)

■The data can be accessed from via PC (setting tool).





The setting and monitoring of the IO-Link unit and device are possible via PC, without using the PLC.


- Process data
- · Device parameters, IO-Link unit parameters
- IO-Link unit information, Device information
- Port diagnosis, Device diagnosis
- The PC setting tool is an IO-Link device tool manufactured by Technologie Management Gruppe (hereinafter referred to as TMG). It can be downloaded for free from the TMG website, however, for usage beyond 30 days, a license key is required.



■ Diagnosis function

Diagnosis is possible from the upper level communication.

IO-Link unit (port) diagnostic information can be obtained via PLC program or PC (web browser). Device diagnostic information can be obtained via PC (setting tool).



| Items of IO-Link unit (port) diagnosis | s |
|--|---|
| Detection of port short-circuit | |

Detection of non-connected device

Detection of misconnected device (check error)

Notification of port misconfiguration (excessively large input/output data)

Conditions of diagnostic event (port, device)

Items of device diagnosis


Diagnostic results (problem phenomenon) received from devices are shown in event codes.

■ Device parameter setting function, Automatic saving/writing

The parameter setting of devices is possible from the upper level communication.

Parameter setting is possible via PC (setting tool).


It is also possible to use output data or message data via PLC program.



EtherNet Fieldbus Functions


PROFINET (EX600-SPN3/4) and EtherNet/IP™ (EX600-SEN3/4) support the following functions.

■ Compatible topologies (Connection configuration)



For ring networks, communication can be continued even if one of the communication cables in the network is disconnected or damaged. As the EX600-SEN3/4 supports Device Level Ring (DLR), and the EX600-SPN3/4 supports Media Redundancy Protocol (MRP), the disconnected point can be identified.

* In order to use DLR or MRP, the PLC must be able to support it.



■ Supports the QuickConnect[™] function and the Fast Start Up function

Time from power ON to communication connection

Approx.


10 S

O-5 s

In the case of a tool changer, it takes about 10 seconds for communication to be connected in some products after the power to the device installed on the tool is turned ON.

As the EX600-SEN3/4 supports the QuickConnect™ function, and the EX600-SPN3/4 supports the Fast Start Up function, communication connection in only approx. 0.5 s is possible.


 In order to use the QuickConnect™ function or the Fast Start Up function, the PLC must be able to support it.



■ Built-in web server function

The EX600-SEN3/4 and EX600-SPN3/4 have a built-in web server function, which enables status checks, parameter settings (EX600-SEN3/4 only), and forced output of the EX600 using general-purpose web browsers, such as Microsoft Edge.

Start-up of the system and maintenance can be performed efficiently.




Connection example

Latest PROFINET Technology

■System Redundancy S2

As the EX600-SPN3/4 supports System Redundancy S2, it can continue communication using the backup controller when the primary controller malfunctions. This allows for the prevention of problems caused by unexpected communication interruption.

 In order to use System Redundancy S2, the PLC must be able to support this function.





Fieldbus System EX600

D-sub connector


IP40

These units are capable of connection using a D-sub connector. There are three types of units: for digital input, output, and input/output. The digital output unit can be connected with an SMC manifold solenoid valve F kit (D-sub connector).

Manifold solenoid valves/Vacuum unit can be connected using a cable with a D-sub connector.

- SY series ZK2□A series
- S0700 series SV series VQC series
- VQ series
- SQ series JSY series
- * Please limit the number of valve connections to 16 stations for single and 8 stations for double. Refer to the catalog of each product for pin assignment details.


VVZS3000-21A-\(\subseteq\)-X192 (Non-waterproof cable example)



■ Spring type terminal block

IP40


These terminal block units are compatible with individual wiring configurations. There are three types of units: for digital input, output, and input/output. Wiring connection to a sensor connector box, etc., can be carried out easily using only a flat head screwdriver.



■ Digital input unit




This unit is for inputting a digital signal (ON/OFF signal). The signal of a 2-wire/3-wire auto switch attached to the actuator can be acquired to feedback a signal to the PLC. The control signal of an entire system can be managed by a Fieldbus system.



Analog input/output unit

These units are for inputting or outputting an analog signal (voltage/current). A single unit performs both input and output, allowing feedback control where analog signals are received from a pressure sensor and sent to a pressure controller. Installation space is minimized as well.



Self-diagnosis function

The following shows examples of the self-diagnosis function.

Short/Open-circuit detection

It is possible to detect short or open circuits of input devices such as electronic 2-wire switches and 3-wire switches and output devices such as solenoid valves. The location of the error can be identified by the indicator light and the network.





Red ON Short circuit

Counter function

It is possible to ascertain the maintenance period and identify the parts that require maintenance by an input and output signal ON/OFF counter function. When the counter function is enabled and a certain number of contact operations is reached, the display of the counter will flash in red.


* The counter function is not provided with analog units.

■Individual units can be connected and removed one by one.

A unique clamping method is adopted to prevent screws from falling out. Units can be separated easily by loosening the joint bracket.

Up to 9 units can be connected in any order.

* Excludes SI units






CONTENTS

Type 3 Integrated input-output type

Fieldbus System (For Input/Output) **EX600** Series





| Parts Structure ····· | D. | 1405 |
|---|----------------|----------------------|
| How to Order | | |
| SI Unit ····· | p. | 1405 |
| Digital Input Unit ····· | | |
| Digital Output Unit ····· | | |
| Digital Input/Output Unit ····· | p. | 1406 |
| Analog Input Unit ····· | p. | 1406 |
| Analog Output Unit ····· | | |
| Analog Input/Output Unit ····· | | |
| IO-Link Unit ····· | | |
| End Plate (D side) | | |
| Handheld Terminal ····· | | |
| Specifications | | |
| All Units Common ····· | p. | 1408 |
| SI Unit ····· | | |
| Digital Input Unit ····· | | |
| Digital Output Unit ····· | D. | 1412 |
| Digital Input/Output Unit ······ | D. | 1412 |
| Analog Input Unit ······ | | |
| Analog Output Unit ····· | | |
| Analog Input/Output Unit ······ | | |
| IO-Link Unit ····· | | |
| End Plate ······ | | |
| Handheld Terminal ····· | | |
| Dimensions | | |
| Parts Description ······ | | |
| LED Indicator ······ | n. | 1423 |
| | | |
| Accessories | | |
| End Plate Bracket | p. | 1427 |
| 2 Valve Plate ····· | | |
| 3 End Plate (U side) ······ | | |
| 4 Reinforcing Brace | | |
| 5 Seal Cap (10 pcs.) | | |
| 6 Marker (1 sheet, 88 pcs.) | | |
| Power Supply Cable (7/8 inch connector) ······· | p. | 1429 |
| Power Supply Field-wireable | | |
| Connector (7/8 inch) ····· | p. | 1429 |
| Power Supply Cable | | |
| (M12 connector, For EX600-ED2) ····· | p. | 1429 |
| Power Supply Cable | | |
| (M12 connector, For EX600-ED4/5) ······ | p. | 1430 |
| Communication Cable | | |
| Prield-wireable Communication Connector | p. | 1435 |
| I O Cable with Connector, I/O Connector ········ | p. | 1436 |
| With Confidence, We confidence | | |
| Will Collineated, We confident | | |
| Made to Order | | |
| Made to Order ① Ethernet POWERLINK compatible | p. | 1438 |
| Made to Order ① Ethernet POWERLINK compatible | p. | 1438 |
| Made to Order ① Ethernet POWERLINK compatible | р. р. | 1438 1438 |
| Made to Order ① Ethernet POWERLINK compatible | р. р. | 1438 1438 |
| Made to Order ① Ethernet POWERLINK compatible | р. р. р. | 1438 1438 1439 |

Fieldbus System


For Input/Output (C C C C



RoHS

EX600 Series

Parts Structure



As a substitute, please consider the use of an EX260 series product. However, keep in mind that the product specifications, external appearance, etc., differ. For details, please contact your SMC sales representative.

Specifications 6

How to Order

SI Unit

End Plate

EX600-S PR1A

| | | | opcomoditions - |
|---------|------------------|-----------------------|---------------------------------|
| Symbol | Protocol | Output type | Note |
| PR1A | PROFIBUS DP | PNP (Negative common) | _ |
| PR2A | PROFIBUS DP | NPN (Positive common) | _ |
| DN1A | DeviceNet® | PNP (Negative common) | _ |
| DN2A | Devicemen | NPN (Positive common) | _ |
| MJ1 | CC-Link | PNP (Negative common) | _ |
| MJ2 | CC-LINK | NPN (Positive common) | _ |
| CF1-X60 | CC-Link IE Field | PNP (Negative common) | (Made to order) |
| EN3 | | PNP (Negative common) | 2 ports |
| EN4 | EtherNet/IP™ | NPN(Positive common) | 2 ports |
| EN3-X80 | Ellelinel/IP···· | PNP (Negative common) | IO-Link unit (Made to order) |
| EC1 | E45 OAT | PNP (Negative common) | _ |
| EC2 | EtherCAT | NPN (Positive common) | _ |
| PN1 | PROFINET | PNP (Negative common) | _ |
| PN2 | | NPN (Positive common) | _ |
| PN3 | | PNP (Negative common) | IO-Link unit |
| PN4 | | NPN (Positive common) | IO-Link unit |

Made to order

| | (neier to page 1430.) | | |
|--------------------------------|-----------------------|--|--|
| | Ethernet POWERLINK | | |
| Modbus TCP CC-Link IE Field | | | |
| | | | |



How to Order

Digital Input Unit

EX600-DXPD



Input type

| Symbol | Description |
|--------|-------------|
| Р | PNP |
| N | NPN |


Number of inputs, open-circuit detection,

and connector

| Symbol | Number of inputs | Open-circuit detection | Connector |
|--------|---------------------|---------------------------|--------------------------------------|
| В | 8 inputs | No | M12 connector (5 pins) 4 pcs. |
| С | 8 inputs | No | M8 connector (3 pins) 8 pcs. |
| C1 | 8 inputs | Yes | M8 connector (3 pins) 8 pcs. |
| D | 16 inputs | No | M12 connector (5 pins) 8 pcs. |
| E | 16 inputs | | D-sub connector (25 pins) |
| F | 16 inputs | No | Spring type terminal block (32 pins) |

Digital Output Unit

EX600-DY PB




| | Output type |
|------|-------------|
| nbol | Description |
| Р | PNP |
| | NIDNI |

Number of outputs and connector

| Symbol | Number of outputs | Connector M12 connector (5 pins) 4 pcs. | |
|--------|----------------------|---|--|
| В | 8 outputs | | |
| E | 16 outputs | D-sub connector (25 pins) | |
| F | 16 outputs | Spring type terminal block (32 pins) | |

Digital Input/Output Unit EX600-DMPF





Input/Output type

| ••• | | darbar rybe - |
|-----|--------|---------------|
| | Symbol | Description |
| | Р | PNP |
| | N | NPN |

Number of inputs/outputs and connector

| Symbol | Number of inputs | Number of outputs | Connector |
|--------|---------------------|----------------------|--------------------------------------|
| Е | 8 inputs | 8 outputs | D-sub connector (25 pins) |
| F | 8 inputs | 8 outputs | Spring type terminal block (32 pins) |

Analog Input Unit

EX600-AXA






| INU | Mulliber of Input challiles and connector | | | | |
|--------|---|-------------------------------|--|--|--|
| Symbol | Number of input channels | Connector | | | |
| Α | 2 channels | M12 connector (5 pins) 2 pcs. | | | |




Analog Output Unit

EX600-AYA









How to Order

Analog Input/Output Unit EX600 - AMB


Analog input/output

Number of input/output channels and connector

| Symbol | Number of input channels | Number of output channels | Connector |
|--------|--------------------------|------------------------------|-------------------------------|
| В | 2 channels | 2 channels | M12 connector (5 pins) 4 pcs. |

IO-Link Unit

EX600-LAB1



| 1 ort opcomount | | i oit opcomounom |
|-----------------|--------|------------------|
| | Symbol | Description |
| | Α | Port class A |
| | В | Port class B |
| | | |

Number of ports and connector


| Symbol | Number of ports | Connector |
|--------|-----------------|----------------------------------|
| В | 4 ports | M12 connector (5 pins) 4 pcs. |

The only available SI unit part numbers are "EX600-SEN3-X80" (EtherNet/IP™ compatible) and "EX600-SPN3/4" (PROFINET compatible). Refer to page 1405.

End Plate (D side)

EX600-ED 2

EX600-ED4/5 are not yet UL-compliant.



For M12

End plate

End plate mounting position: D side

| ì | | i ower supply com | iccioi • |
|-------------------------------|---|--------------------------|----------|
| Symbol Power supply connector | | Specifications | |
| | 2 | M12 (5 pins) B-coded | IN |
| 3 7/8 inch (5 pins) | | 7/8 inch (5 pins) | IN |
| | 4 | M12 (4/5 pins) A-coded*1 | IN/OUT |
| | 5 | M12 (4/5 pins) A-coded*1 | IN/OUT |

*1 The pin layout for the "4" and "5" pin connectors is different.

Refer to the dimensions on page 1417.

Mounting method

| | Symbol | Description | Note |
|--|--------|-----------------------------------|-------------------------------|
| | Nil | Without DIN rail mounting bracket | _ |
| | 2 | With DIN rail mounting bracket | For SV, S0700, and VQC series |
| | 3 | With DIN rail mounting bracket | For SY, JSY, and ZK2□A series |
| | | | |

* When the end plate (U side) is used, the symbol for the mounting method must be the same as the D side.

Handheld Terminal

For 7/8 inch

EX600-HT1A

Handheld terminals are not yet UL-compliant.



Cable length

| Symbol | Description | |
|--------|-------------|--|
| Nil | No cable | |
| 1 | 1 m | |
| 3 | 3 m | |

All Units Common Specifications

| E | Operating temperature range Operating humidity range Withstand voltage*1 | Operating: -10 to 50°C, Stored: -20 to 60°C |
|--------|--|--|
| ۱Ĕ | Operating humidity range | 35 to 85% RH (No condensation) |
| Enviro | Withstand voltage*1 | 500 VAC for 1 minute between external terminals and FE |
| | Insulation resistance*1 | 500 VDC, 10 MΩ or more between external terminals and FE |

^{*1} Except handheld terminals

SI Unit (EX600-SPR□A)

| | (2.1000 0.11.2.1) | | | | |
|---------------|--|--|----------------------------|--|--|
| | Model | EX600-SPR1A | EX600-SPR2A | | |
| 5 | Protocol | PROFIBUS | | | |
| 量 | Device type | PROFIBUS DP Slave | | | |
| 은 | Communication speed | 9.6/19.2/45.45/93.75/187.5/500 kbps 1.5/3/6/12 Mbps | | | |
| ⊒ | Configuration file | GSD | file*2 | | |
| Communication | Occupation area (Number of inputs/outputs) | Max. (512 inputs/512 outputs) | | | |
| | rminating resistor | Internally in | plemented | | |
| Int (Po | ernal current consumption over supply for Control/Input) | 80 mA or less | | | |
| | Output type | Source/PNP (Negative common) | Sink/NPN (Positive common) | | |
| - | Number of outputs | 32 outputs (8/16/24/3 | 2 outputs selectable) | | |
| Output | Load | Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC) | | | |
| ١Ę | Power supply | 24 VDC, 2 A | | | |
| ١ | Fail safe | HOLD/CLEAR/F | orced power ON | | |
| | Protection | Short-circuit protection | | | |
| Er | closure | IP67 (Manifold assembly) | | | |
| St | andards | CE/UKCA marking, UL (CSA) | | | |
| W | eight | 300 g | | | |

^{*2} The configuration file can be downloaded from the SMC website: https://www.smcworld.com

SI Unit (EX600-SDN□A)

| Model | | EX600-SDN1A | EX600-SDN2A | |
|--------------|---|---|-------------------------------------|--|
| | Protocol | DeviceNet®: Volume 1 (Editio | n 2.1), Volume 3 (Edition 1.1) | |
| _ | Device type | Group 2 Only Server | | |
| ₽ | Communication speed | 125/250/ | 500 kbps | |
| <u>8</u> | Configuration file | EDS | file*3 | |
| ommunication | Occupation area (Number of inputs/outputs) | Max. (512 inpu | ts/512 outputs) | |
| 5 | Applicable messages | Duplicate MAC ID Check Message, Grou Explicit Message (Group 2), Poll I/O Me | | |
| | Applicable function | QuickCo | nnect™ | |
| De | eviceNet® power supply | 11 to 25 VDC (Current consumption 50 mA or less) | | |
| Int (Po | ernal current consumption ower supply for Control/Input) | 55 mA or less | | |
| | Output type | Source/PNP (Negative common) | Sink/NPN (Positive common) | |
| - | Number of outputs | 32 outputs (8/16/24/32 outputs selectable) | | |
| utbut | Load | Solenoid valve with surge voltage sup | pressor 24 VDC, 1.5 W or less (SMC) | |
| Įξ | Power supply | 24 VDC, 2 A | | |
| ١ | Fail safe | HOLD/CLEAR/F | orced power ON | |
| | Protection | Short-circui | t protection | |
| Er | closure | IP67 (Manifold assembly) | | |
| Standards | | CE/UKCA marking, UL (CSA) | | |
| Weight | | 300 g | | |
| *3 | 3 The configuration file can be downloaded from the SMC website: https://www.smcworld.com | | | |

³ The configuration file can be downloaded from the SMC website: https://www.smcworld.com



| | Model | EX600-SMJ1 | EX600-SMJ2 |
|---------------|--|---|----------------------------|
| Ĕ | Protocol | CC-Link (Ver. 1.10, Ver. 2.00) | |
| lĕ | Station type | Remote De | vice Station |
| 읃 | Communication speed | 156/625 kbps | 2.5/5/10 Mbps |
| 뎥 | Configuration file | CSP+ | file*4 |
| Communication | Occupation area (Number of inputs/outputs) | Max. (512 inputs/512 outputs) 1/2/3/4 stations occupied | |
| Int (Pc | ernal current consumption ower supply for Control/Input) | 75 mA or less | |
| | Output type | Source/PNP (Negative common) | Sink/NPN (Positive common) |
| - | Number of outputs | 32 outputs (8/16/24/32 outputs selectable) | |
| Output | Load | Solenoid valve with surge voltage suppressor 24 VDC, 1.5 W or less (SMC | |
| ĮΞ | Power supply | 24 VDC, 2 A | |
| ١ | Fail safe | HOLD/CLEAR/F | orced power ON |
| | Protection | Short-circui | t protection |
| Er | closure | IP67 (Manifold assembly) | |
| Standards | | CE/UKCA marking, UL (CSA) | |
| Weight | | 30 | 0 g |

^{*4} The configuration file can be downloaded from the SMC website: https://www.smcworld.com





EX600-SDN□A





SI Unit (EX600-SCF1-X60)

| Model | | EX600-SCF1-X60*1 | |
|---------------|--|--|--|
| | Protocol | CC-Link IE Field | |
| | Station type | Intelligent Device Station | |
| اے ا | Communication speed | 1 Gbps | |
| ₫ | Allowable station number setting | 1 to 120 | |
| <u>8</u> | Allowable network number setting | 1 to 239 | |
| 5 | Transmission method | Cyclic transmission | |
| Communication | Configuration file | CSP+ file*2 | |
| 5 | Occupied input size | RX: 32 to 176 bits | |
| ~ | Occupied input size RWr: 32 to 608 words | | |
| | Occupied output size | RY: 32 to 176 bits | |
| | Occupied output size | RWw: 32 to 608 words | |
| | ernal current consumption wer supply for Control/Input) | 140 mA or less | |
| (1-0 | Output type | Source/PNP (Negative common) | |
| | Number of outputs | 32 outputs | |
| ١ | Number of outputs | · | |
| Output | Load | Solenoid valve with surge voltage suppressor | |
| 15 | | 24 VDC, 1.0 W or less (SMC) | |
| 0 | Power supply | 24 VDC, 2 A | |
| | Fail safe | HOLD/CLEAR/Forced power ON | |
| | Protection | Short-circuit protection | |
| Er | nclosure | IP67 (Manifold assembly) | |
| St | andards | CE/UKCA marking | |
| W | eight | 300 g | |

- *1 For details on this product, refer to the SMC website.
 *2 The configuration file can be downloaded from the SMC website: https://www.smcworld.com



EX600-SEN3/4(-X80)

SI Unit (EX600-SEN□)

| Model | | EX600-SEN3 | EX600-SEN4 | EX600-SEN3-X80 | | |
|---------------|--|--|-------------------------------|-------------------|--|--|
| | Number of communication ports | 2 ports | | | | |
| | Protocol | EtherNet/IP™ | | | | |
| | riotocoi | (Conformance version: Composite 11) | | | | |
| | Communication speed | | 10/100 Mbps | | | |
| | Communication method | | Full duplex/Half duplex | | | |
| 등 | Configuration file | EDS file*3 | | | | |
| Communication | Occupation area (Number of inputs/outputs) | N | Max. (512 inputs/512 outputs) | | | |
| [[| IP address setting | SI Unit sw | vitch settings: 192.168.0 or | 1.1 to 254 | | |
| Ē | range | Throug | gh DHCP server: Optional a | ddress | | |
| ပြ | | Ve | endor ID: 7 (SMC Corporation | on) | | |
| | Device information | Device | type: 12 (Communication A | dapter) | | |
| | | | Product code: 203 | | | |
| | QuickConnect | | | • | | |
| | DLR | • | | • | | |
| | Web server function | • | | • | | |
| 10 | -Link unit | - | | • | | |
| | ernal current consumption ower supply for Control/Input) | 120 mA or less | | | | |
| | Output type | Source/PNP | Sink/NPN | Source/PNP | | |
| | Output type | (Negative common) | (Positive common) | (Negative common) | | |
| | Number of outputs | | 32 outputs | | | |
| Output | Load | Solenoid valve with surge voltage suppressor | | | | |
| ጀ | Load | 24 VDC, 1.0 W or less (SMC) | | | | |
| | Power supply | | 24 VDC, 2 A | | | |
| | Fail safe | HOLD/CLEAR/Forced power ON | | | | |
| Protection | | Short-circuit protection | | | | |
| Enclosure | | IP67 (Manifold assembly) | | | | |
| | andards | CE/UKCA marking, UL (CSA) | | | | |
| W | eight | | 300 g | | | |
| _ | | be desirated from the CMC websites bitmes//www.emesserid.com | | | | |

^{*3} The configuration file can be downloaded from the SMC website: https://www.smcworld.com



EX600-SEC1 and EX600-SEC2 EtherCAT compatible SI units are to be discontinued as of October 2022.

As a substitute, please consider the use of an EX260 series product. However, keep in mind that the product specifications, external appearance, etc., differ. For details, please contact your SMC sales representative.

SI Unit (EX600-SECT)



| | Model | EX600-SEC1 | EX600-SEC2 | | | | |
|---------------|--|--|-------------------------------------|--|--|--|--|
| 8 | Protocol | EtherCAT (Conformance Test Record V.1.2) | | | | | |
| gi | Communication speed | 100 1 | Mbps | | | | |
| Ē | Configuration file | XML | file*1 | | | | |
| Communication | Occupation area (Number of inputs/outputs) | Max. (512 inputs/512 outputs) | | | | | |
| | ernal current consumption over supply for Control/Input) | 100 mA or less | | | | | |
| | Output type | Source/PNP (Negative common) | Sink/NPN (Positive common) | | | | |
| | Number of outputs | 32 outputs (8/16/24/32 outputs selectable) | | | | | |
| Output | Load | Solenoid valve with surge voltage sup | pressor 24 VDC, 1.5 W or less (SMC) | | | | |
| ١Ę | Power supply | 24 VD | C, 2 A | | | | |
| ~ | Fail safe | HOLD/CLEAR/F | orced power ON | | | | |
| | Protection | Short-circuit protection | | | | | |
| En | closure | IP67 (Manifold assembly) | | | | | |
| St | andards | CE/UKCA marking, UL (CSA) | | | | | |
| We | eight | 30 | O g | | | | |

^{*1} The configuration file can be downloaded from the SMC website: https://www.smcworld.com

SI Unit (EX600-SPN)



EX600-SPN1/2




EX600-SPN3/4


| | Model | EX600-SPN1 | EX600-SPN2 | EX600-SPN3 | EX600-SPN4 | |
|--------------|---------------------------------|----------------------------|----------------------|----------------------|---|--|
| | | PROFI | | PROFINET IO | | |
| | Protocol | | ce Class B) | | ce Class C) | |
| 6 | Communication speed | (00 | | Mbps | | |
| 黃 | Configuration file | | GSDM | | | |
| ≝ | Fast Start Up | | A GODIN | L 1110 | | |
| ₹ | (Communication connection time) | (Annro | x. 2 s) | (Approx | 500 ms) | |
| Communicatio | MRP | (, ibb.c | - | (лфргол. | • | |
| ပ | System Redundancy S2 | _ | _ | | | |
| | Web server | _ | _ | | | |
| 10 | -Link unit | _ | | | | |
| Cı | irrent consumption | 120 mA or less | | | | |
| | Outrout trong | Source/PNP | Sink/NPN | Source/PNP | Sink/NPN | |
| L | Output type | (Negative common) | (Positive common) | (Negative common) | (Positive common) | |
| utput | Number of outputs | 32 outputs | | | | |
| ١Ħ | Load | Solenoid valve wi | th surge voltage sup | pressor 24 VDC, 1.0 | W or less (SMC) | |
| ١ | Fail safe | HOLD/CLEAR/Forced power ON | | | | |
| Protection | | | Short-circui | t-circuit protection | | |
| Er | closure | IP67 (Manifold assembly) | | | | |
| St | andards | CE/UKCA marking, UL (CSA) | | | | |
| W | eight | 300 g | | | | |

^{*2} The configuration file can be downloaded from the SMC website: https://www.smcworld.com






EX600-DX□B




EX600-DX□C□



EX600-DX□D



EX600-DX□E



EX600-DX□F


Digital Input Unit

| 2.g.tapat 0 | | | | | | | | |
|-------------|---------------------------|---------|--|------------------|-----------------|------------------|------------------|------------------|
| | Model | | EX600-DXPB | EX600-DXNB | EX600-DXPC□ | EX600-DXNC□ | EX600-DXPD | EX600-DXND |
| | Input type | | PNP | NPN | PNP | NPN | PNP | NPN |
| | Input connecto | r | M12 (5-pir | n) socket*1 | M8 (3-pin |) socket*3 | M12 (5-pir | n) socket*1 |
| | Number of inpu | uts | 8 inputs (2 inp | uts/Connector) | 8 inputs (1 inp | ut/Connector) | 16 inputs (2 inp | uts/Connector) |
| | Supplied voltage | ge | | | 24 \ | /DC | | |
| | Max. supplied current | | | onnector Unit | | onnector Unit | | onnector Unit |
| Input | Protection | | Short-circuit protection | | | | | |
| = | Input current (at | 24 VDC) | 9 mA or less | | | | | |
| | ON voltage | | 17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V) | | | | | |
| | OFF voltage | | 5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V) | | | | | |
| | Open circuit | 2 wires | - | _ | 0.5 mA | /Input*2 | - | _ |
| | detection current 3 wires | | - | _ | 0.5 mA/Cd | onnector*2 | - | _ |
| Cı | Current consumption | | 50 mA | or less | 55 mA | or less | 70 mA | or less |
| Er | closure | | IP67 (Manifold assembly) | | | | | |
| St | andards | | CE/UKCA marking, UL (CSA) | | | | | |
| W | eight | | 30 | 0 g | 27 | 5 g | 34 | 0 g |


- *1 M12 (4-pin) connector can be connected.
- *3 When connecting the M8 plug connector, the tightening torque must be 0.2 N·m ±10%. If tightened with an excessive tightening torque, this may cause the connector thread of the unit to break.

| Model | | EX600-DXPE | EX600-DXNE | EX600-DXPF | EX600-DXNF | | |
|-----------|---------------------------|--|---|---|-------------------------|--|--|
| | Input type | PNP | NPN | PNP | NPN | | |
| | Input connector | | et (25 pins) No.4-40 UNC | Spring type terming | nal block (32 pins) | | |
| | Number of inputs | 16 ir | nputs | 16 inputs (2 inp | outs x 8 blocks) | | |
| | Supplied voltage | | 24 \ | /DC | | | |
| nbnt | Max. supplied current | 2 A/ | 2 A/Unit | | 0.5 A/Block 2 A/Unit | | |
| _ | Protection | Short-circuit protection | | | | | |
| | Input current (at 24 VDC) | | 5 mA or less | | | | |
| | ON voltage | | 17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V) | | | | |
| | OFF voltage | 5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 V (At PNP input, between the pin for input terminal and supplied voltage of 0 V) | | | | | |
| Αŗ | plicable wire | - | _ | 0.08 to 1.5 mm ² (AWG16 to 28) | | | |
| Cı | rrent consumption | 50 mA or less | | | or less | | |
| Er | closure | IP40 (Manifold assembly) | | | | | |
| Standards | | CE/UKCA marking, UL (CSA) | | | | | |
| W | eight | 300 g | | | | | |

Specifications



EX600-DY□E EX600-DM□E



EX600-DY□F EX600-DM□F


Digital Output Unit

| | gitai Output Oilit | | | | | | | |
|-----------|--------------------|---|--------------------------|------------|---|------------------|--------------------------------------|--|
| | Model | EX600-DYPB | EX600-DYNB | EX600-DYPE | EX600-DYNE | EX600-DYPF | EX600-DYNF | |
| | Output type | PNP | NPN | PNP | NPN | PNP | NPN | |
| | Output connector | M12 (5-pir | M12 (5-pin) socket*1 | | D-sub socket (25 pins) Lock screw: No.4-40 UNC | | Spring type terminal block (32 pins) | |
| ΙĒ | Number of outputs | 8 outputs (2 out | puts/Connector) | 16 ou | itputs | 16 outputs (2 ou | tputs x 8 blocks) | |
| Output | Supplied voltage | | 24 VDC | | | | | |
| | Max. load current | | 0.5 A/Output 2 A/Unit | | | | | |
| | Protection | Short-circuit protection | | | | | | |
| Ap | oplicable wire | | | | 1.5 mm ² 6 to 28) | | | |
| Cı | urrent consumption | 50 mA or less | | | | | | |
| Enclosure | | IP67 IP40 (Manifold assembly) (Manifold assembly) | | | | | | |
| St | andards | CE/UKCA marking, UL (CSA) | | | | | | |
| Weight | | 300 g | | | | | | |

^{*1} M12 (4-pin) connector can be connected.

Digital Input/Output Unit

| Ë | Model | EX600-DMPE | EX600-DMNE | EX600-DMPF | EX600-DMNF | |
|--------|---------------------------|--|-----------------------------|----------------------------------|---------------------|--|
| In | put/Output type | PNP | NPN | PNP | NPN | |
| г | onnector | D-sub sock Lock screw: I | et (25 pins) No.4-40 UNC | Spring type terming | nal block (32 pins) | |
| | Number of inputs | 8 in | outs | 8 inputs (2 inp | uts x 4 blocks) | |
| | Supplied voltage | | 24 \ | /DC | | |
| | Max. supplied current | 2 A/ | Unit | | /Block /Unit | |
| Input | Protection | | Short-circuit protection | | | |
| 빌 | Input current (at 24 VDC) | | 5 mA | or less | | |
| | ON voltage | 17 V or more (At NPN input, between the pin for input terminal and supplied voltage of +24 V) (At PNP input, between the pin for input terminal and supplied voltage of 0 V) | | | | |
| | OFF voltage | 5 V or less (At NPN input, between the pin for input terminal and supplied voltage of +24 V (At PNP input, between the pin for input terminal and supplied voltage of 0 V) | | | | |
| | Number of outputs | 8 out | tputs | 8 outputs (2 outputs x 4 blocks) | | |
| 5 | Supplied voltage | | 24 \ | /DC | | |
| Output | Max. load current | 0.5 A/Output 2 A/Unit | | | | |
| | Protection | | Short-circu | t protection | | |
| A | oplicable wire | - | _ | 0.08 to 1.5 mm ² | 2 (AWG16 to 28) | |
| Cı | urrent consumption | 50 mA | or less | 60 mA | or less | |
| Er | nclosure | IP40 (Manifold assembly) | | | | |
| St | andards | CE/UKCA marking, UL (CSA) | | | | |
| W | eight | 300 g | | | | |



Analog Input Unit

| | Model | | EX600 |)-AXA | |
|-------|----------------------------|-------------------|-------------------------------|------------------------|--|
| | Input type | | Voltage input | Current input | |
| | Input conn | ector | M12 (5-pir | n) socket*1 | |
| | Input chan | nel | 2 channels (1 ch | annel/Connector) | |
| | Supplied v | oltage | 24 \ | /DC | |
| | Max. suppl | ied current | 0.5 A/Co | onnector | |
| ا ـِ | Protection | | Short-circu | it protection | |
| Input | Input | 12 bit resolution | 0 to 10 V, 1 to 5 V, 0 to 5 V | 0 to 20 mA, 4 to 20 mA | |
| = | signal range 16 bit resolu | | -10 to 10 V, -5 to 5 V | –20 to 20 mA | |
| | Max. rated input signal | | ±15 V | ±22 mA*2 | |
| | Input impedance | | 100 kΩ | 50 Ω | |
| | Linearity (25°C) | | ±0.05% F.S. | | |
| | Repeatabil | ity (25°C) | ±0.15° | % F.S. | |
| | Absolute acc | curacy (25°C) | ±0.5% F.S. | ±0.6% F.S. | |
| Cı | Current consumption | | 70 mA or less | | |
| En | Enclosure | | IP67 (Manifold assembly) | | |
| Sta | Standards | | CE/UKCA marking, UL (CSA) | | |
| We | eight | | 29 | 0 g | |

- *1 M12 (4-pin) connector can be connected.
 *2 When input signal exceeds 22 mA, the protection function activates and the input signal is interrupted.




Analog Output Unit

| | Mod | el | EX600 | D-AYA | |
|--------|---------------------|-------------------|----------------------------------|------------------------|--|
| | Output type | | Voltage output | Current output | |
| | Output con | nector | M12 (5-pin) socket*3 | | |
| | Output cha | nnel | 2 channels (1 channel/Connector) | | |
| | Supplied v | oltage | 24 \ | /DC | |
| ١ | Max. load o | urrent | 0.5 A/Cd | onnector | |
| Output | Protection | | Short-circuit protection | | |
| 8 | Output signal range | 12 bit resolution | 0 to 10 V, 1 to 5 V, 0 to 5 V | 0 to 20 mA, 4 to 20 mA | |
| | Load impedance | | 1 kΩ or more | 600 Ω or less | |
| | Linearity (25°C) | | ±0.05% F.S. | | |
| | Repeatabil | ity (25°C) | ±0.15% F.S. | | |
| | Absolute acc | curacy (25°C) | ±0.5% F.S. | ±0.6% F.S. | |
| Cı | Current consumption | | 70 mA or less | | |
| Eı | Enclosure | | IP67 (Manifold assembly) | | |
| St | andards | | CE/UKCA marking, UL (CSA) | | |
| W | eight | | 29 | 0 g | |

^{*3} M12 (4-pin) connector can be connected.

Specifications



Analog Input/Output Unit

| | Model | | D-AMB | | | |
|--------|---------------------------------------|----------------------------------|------------------------|--|--|--|
| | Input type | Voltage input | Current input | | | |
| | Input connector | M12 (5-pin) socket*1 | | | | |
| | Input channel | 2 channels (1 channel/Connector) | | | | |
| | Supplied voltage | 24 VDC | | | | |
| | Max. supplied curren | 0.5 A/Co | onnector | | | |
| ų. | Protection | Short-circui | it protection | | | |
| Input | Input signal range 12 bit resolution | 0 to 10 V, 1 to 5 V, 0 to 5 V | 0 to 20 mA, 4 to 20 mA | | | |
| | Max. rated input signa | 15 V | 22 mA*2 | | | |
| | Input impedance | 100 kΩ | 250 Ω | | | |
| | Linearity (25°C) | ±0.05° | % F.S. | | | |
| | Repeatability (25°C) | ±0.15% F.S. | | | | |
| | Absolute accuracy (25°C | ±0.5% F.S. | ±0.6% F.S. | | | |
| | Output type | Voltage output | Current output | | | |
| | Output connector | M12 (5-pir | n) socket*1 | | | |
| | Output channel | 2 channels (1 channel/Connector) | | | | |
| | Supplied voltage | 24 VDC | | | | |
| | Max. load current | 0.5 A/Connector | | | | |
| Jutput | Protection | Short-circu | it protection | | | |
| 9 | Output signal range 12 bit resolution | 0 to 10 V, 1 to 5 V, 0 to 5 V | 0 to 20 mA, 4 to 20 mA | | | |
| | Load impedance | 1 kΩ or more | 600 Ω or less | | | |
| | Linearity (25°C) | ±0.05° | % F.S. | | | |
| | Repeatability (25°C) | ±0.15° | % F.S. | | | |
| | Absolute accuracy (25°C | ±0.5% F.S. | ±0.6% F.S. | | | |
| С | urrent consumption | 100 mA | A or less | | | |
| E | nclosure | IP67 (Manifo | ld assembly) | | | |
| S | tandards | CE/UKCA mar | king, UL (CSA) | | | |
| W | /eight | 300 g | | | | |

^{*1} M12 (4-pin) connector can be connected.
*2 When input signal exceeds 22 mA, the protection function activates and the input signal is interrupted.



IO-Link Unit

| Model | | EX600 | -LAB1 | EX600-LBB1 | | |
|---------------------|------------------------------|---|-------------------------------|--|--|--|
| IO-Link version | | Version 1.1 | | | | |
| 10 | -Link port class | Clas | ss A | Class B | | |
| Communication speed | | COM1 (4.8 kBaud) COM2 (38.4 kBaud) COM3 (230.4 kBaud) * Changes automatically according to the connected device | | | | |
| Νι | umber of IO-Link ports | | 4 | 4 | | |
| | ompatible SI unit rotocol) | | | 4 (PROFINET) 0 (EtherNet/IP™) | | |
| Max. supply current | Device power supply (L+) | 0.5 A/Co (2 A/ | onnector 'Unit) | 0.5 A/Connector (1 A/Unit) | | |
| Max. supp | External power supply (P24) | _ | | 1.6 A/Connector (3 A/Unit) | | |
| | Pin no. | 2 | 4 | 4 | | |
| | Input type | PNP | | | | |
| Input | Protection | | Short-circui | it protection | | |
| 트 | Rated input current | Approx. 2.5 mA | Approx. 2.5 mA Approx. 5.8 mA | | | |
| | ON voltage | | 13 V o | r more | | |
| | OFF voltage | | 8 V o | rless | | |
| | Pin no. | | | 4 | | |
| 털 | Output type | | Ph | NP | | |
| Output | Max. load current (C/Q line) | (Sup | | /Output r supply for control/input) | | |
| | Protection | Short-circuit protection | | | | |
| Cı | urrent consumption | 50 mA or less | | | | |
| Er | nclosure | IP67 (Manifold assembly) | | | | |
| St | andards | CE/UKCA marking, UL (CSA) | | | | |
| W | eight | | 32 | 0 g | | |





EX600-ED2-□ EX600-ED4/5-□



EX600-ED3-□

End Plate

| | Model | | EX600-ED2-□ | EX600-ED3-□ | EX600-ED4/5- | |
|----------------|--------------|--------------------------------|---------------------------|-----------------------|--------------------|--|
| ns. | Power supply | PWR IN | M12 (5-pin) plug | 7/8 inch (5-pin) plug | M12 (4-pin) plug | |
| specifications | connector | PWR OUT | _ | _ | M12 (5-pin) socket | |
| ≗ | Rated | Power supply for control/input | | 24 VDC ±10% | | |
| | voltage | Power supply for output | | 24 VDC +10/-5% | | |
| Power | Rated | Power supply for control/input | Max. 2 A | Max. 8 A | Max. 4 A | |
| 8 | current | Power supply for output | Wax. 2 A | IVIAX. 6 A | IVIAX. 4 A | |
| En | closure | | IP67 (Manifold assembly) | | | |
| St | Standards*1 | | CE/UKCA marking, UL (CSA) | | | |
| W | eight | | 170 g | 175 g | 170 g | |

^{*1} The EX600-ED4/5-□ is not compliant with UL (CSA) standards.

Handheld Terminal

| EX600-HT1A-□ | |
|---|--|
| Power supplied from SI unit connector (24 VDC) | |
| 50 mA or less | |
| LCD with backlight | |
| Handheld terminal cable (1 m ··· EX600-AC010-1, 3 m ··· EX600-AC030-1) | |
| IP20 | |
| CE/UKCA marking | |
| 160 g | |
| | |


^{*1} The handheld terminal is not compliant with UL (CSA) standards.
* Cannot be used with the EX600-SPN3/4 and EX600-LAB1/LBB1







Dimensions


SI Unit




EX600-SEN□(-X80) EX600-SEC□ EX600-SPN1/2









EX600-SPN3/4










Dimensions

End Plate (D side)





EX600-ED4/ED5 85.1 FE terminal



Power supply connector PWR IN: M12 5-pin plug, B-coded

| Configuration | EX600-ED2 | | |
|---------------|-----------|--------------------------|--|
| Configuration | Pin no. | Description | |
| | 1 | 24 V (for output) | |
| 2001 | 2 | 0 V (for output) | |
| 5(00) | 3 | 24 V (for control/input) | |
| 3 4 | 4 | 0 V (for control/input) | |
| | 5 | FE | |

Power supply connector PWR IN: M12 4-pin plug, A-coded


| Configuration | EX600-ED4 (Pin arrangement 1) | | EX600-ED5 (Pin arrangement 2) | |
|---------------|-------------------------------|--------------------------|-------------------------------|--------------------------|
| Configuration | Pin no. | Description | Pin no. | Description |
| 3 _ 2 | 1 | 24 V (for control/input) | 1 | 24 V (for output) |
| 600 | 2 | 24 V (for output) | 2 | 0 V (for output) |
| (0 9) | 3 | 0 V (for control/input) | 3 | 24 V (for control/input) |
| 4 1 | 4 | 0 V (for output) | 4 | 0 V (for control/input) |


Power supply connector PWR OUT: M12 5-pin socket, A-coded

| | | ED4 (Pin arrangement 1) | (Pin arrangement 1) EX600-ED5 (Pin arrangement 2) | |
|---------------|---------|--------------------------|---|--------------------------|
| Corniguration | Pin no. | Description | Pin no. | Description |
| 1 2 | 1 | 24 V (for control/input) | 1 | 24 V (for output) |
| | 2 | 24 V (for output) | 2 | 0 V (for output) |
| (%) | 3 | 0 V (for control/input) | 3 | 24 V (for control/input) |
| 4 5 3 | 4 | 0 V (for output) | 4 | 0 V (for control/input) |
| . 5 - | 5 | Unused | 5 | Unused |

Dimensions

End Plate (D side) EX600-ED3






Power supply connector PWR: 7/8 inch 5-pin plug

| ower supply connector i wit. 770 men s-pm plug | | | | |
|--|---------|--------------------------|--|--|
| Configuration | Pin no. | Description | | |
| | 1 | 0 V (for output) | | |
| 0 0 | 2 | 0 V (for control/input) | | |
| | 3 | FE | | |
| (O 0 0) | 4 | 24 V (for control/input) | | |
| <u></u> | 5 | 24 V (for output) | | |

22.1




22.1


Dimensions

Analog Unit

EX600-AXA EX600-AYA



EX600-AMB




IO-Link Unit

22.1


56.4

EX600-LAB1 EX600-LBB1



Parts Description

SI Unit




| No. | Name | Use |
|-----|-----------------------------|---|
| 1 | Status indication LED | Displays unit status |
| 2 | Indication cover | Open for setting the switch. |
| 3 | Indication cover set screw | Loosen for opening the indication cover. |
| 4 | Connector (BUS OUT) | Connects to the fieldbus output cable (SPEEDCON)*1 |
| 5 | Marker groove | Can be used to mount a marker |
| 6 | Connector (PCI) | Connects to the handheld terminal cable (SPEEDCON) |
| 7 | Valve plate mounting holes | Fixes a valve plate in place |
| 8 | Valve plate mounting groove | Inserts a valve plate |
| 9 | Joint bracket | Links units to one another |
| 10 | Connector for unit (Plug) | Transmits signals to the neighboring unit and supplies power |
| 11 | Connector (BUS IN) | Connects to the cable for fieldbus input (SPEEDCON)*1 |
| 12 | MAC address name plate*2 | Displays a unique 12-digit MAC address for each SI unit |
| 13 | Seal cap | Mounted on the connectors (BUS OUT and PCI) at the time of shipment |


- *1 The EX600-SPN3/4 is not SPEEDCON compatible.
- *2 MAC address name plate is not provided on the EX600-SEC ...


Digital Unit


EX600-SPN3/4



| No. | Name | Use |
|-----|---------------------------|---|
| 1 | Status indication LED | Displays unit status |
| 2 | Connector | Connects with input or output devices (Only the EX600-DCDB and EX600-DXDD are SPEEDCON compatible.) |
| 3 | Marker groove | Can be used to mount a marker |
| 4 | Lock screw | Secures the D-sub connector in place (No.4-40 UNC) |
| 5 | Joint bracket | Links units to one another |
| 6 | Connector for unit (Plug) | Transmits signals to the neighboring unit and supplies power |









Parts Description

Analog Unit




| No. | Name | Use |
|-----|---------------------------|--|
| 1 | Status indication LED | Displays unit status |
| 2 | Connector | Connects with input or output devices (SPEEDCON) |
| 3 | Marker groove | Can be used to mount a marker |
| 4 | Joint bracket | Links units to one another |
| 5 | Connector for unit (Plug) | Transmits signals to the neighboring unit and supplies power |

IO-Link Unit




| No. | Name | Use |
|-----|---------------------------|--|
| 1 | Status indication LED | Displays unit status |
| 2 | Connector | Connects with IO-Link, input, or output devices (SPEEDCON) |
| 3 | Marker groove | Can be used to mount a marker |
| 4 | Joint bracket | Links units to one another |
| 5 | Connector for unit (Plug) | Transmits signals to the neighboring unit and supplies power |

End Plate




| No. | Name | Use |
|-----|---|--|
| 1 | Power connector (PWR IN) | Supplies power to the unit and/or input/ output device (Only the EX600-ED2/ED4/ ED5-□ is SPEEDCON compatible.) |
| 2 | Fixing hole for direct mounting | Connects directly to equipment |
| 3 | Fixing hole for DIN rail | Converts to manifold or for DIN rail mounting |
| 4 | FE terminal | Used for grounding Ground this terminal securely to improve noise immunity. |
| 5 | Connector (Unused) Power connector (PWR OUT) | Supplies power to the device on the downstream side |




LED Indicator


EX600-SPR□A




EX600-SDN□A




EX600-SEN3/SEN4(-X80)




EX600-SEC□



EX600-SPN1/SPN2




EX600-SPN3/SPN4




LED Indicator


EX600-SMJ□




EX600-DX□B




EX600-DX□C□




EX600-DX□D



EX600-DX□E




EX600-DX□F




LED Indicator


EX600-DY□B




EX600-DY□E




EX600-DY□F




EX600-DM□E



EX600-DM□F



EX600-AXA




LED Indicator


EX600-AYA




EX600-AMB




EX600-LAB1



EX600-LBB1



EX600 Series Accessories



● End Plate Bracket

This bracket is used for the end plate of DIN rail mounting.



EX600-ZMA2

Enclosed parts

Round head screw (M4 x 20) 1 pc. P-tight screw (4 x 14) 2 pcs.

EX600-ZMA3

(Specialized for SY series)

Enclosed parts

Round head screw with washer (M4 x 20) 1 pc. P-tight screw (4 x 14) 2 pcs.

Valve Plate



EX600-ZMV2

(Specialized for SY series)


Enclosed parts

Round head screw (M4 x 6) 2 pcs. Round head screw (M3 x 8) 2 pcs.




1 End Plate (U side)

The end plate is for use when the manifold valve is not connected.





EX600-EU1 28.2 26 2 x M4 direct mounting hole 28.2 2 marked a second and a sec



Enclosed parts

Round head screw (M4 x 5) 2 pcs.

4 Reinforcing Brace

This bracket is used on the bottom of the unit at the intermediate position for connecting 6 units or more.

* Be sure to attach this bracket to prevent connection failure between the units caused by deflection.



For DIN rail mounting EX600-ZMB2

Enclosed parts

Round head screw (M4 x 6) 2 pcs.



Seal Cap (10 pcs.)

Be sure to mount a seal cap on any unused I/O connectors. Otherwise, the specified enclosure cannot be maintained.





6 Marker (1 sheet, 88 pcs.)

The signal name of I/O device and each unit address can be entered and mounted on each unit.




Accessories **EX600** Series

Power Supply Cable (7/8 inch connector)


PCA-1558810 Straight 2 m PCA-1558823 Straight 6 m PCA-1558836 Right angled 2 m PCA-1558849 Right angled 6 m

Straight connector type





Angled connector type



| 1.1 | Ш | | Red/White: 0 V (For output) |
|-----|------|---------|-----------------------------|
| 2 | # | | |
| 3- | | | |
| 4 | ···H | | |
| 5- | | | |
| , | | onne | ections |

| Item | Specifications |
|---------------------------------|----------------------------|
| Cable O.D. | ø12.58 mm |
| Conductor nominal cross section | 1.5 mm ² /AWG16 |
| Wire O.D. (Including insulator) | 2.35 mm |
| Min. bending radius (Fixed) | 110 mm |

Power Supply Field-wireable Connector (7/8 inch)

PCA-1578081 Socket [compatible with AWG22-16]



Applicable Cable

| Item | Specifications |
|--|--|
| Cable O.D. | ø12.0 to 14.0 mm |
| Wire gauge (Stranded wire cross section) | 0.34 to 1.5 mm ² AWG22 to 16 |


Power Supply Cable (M12 connector, For EX600-ED2) * The shape of the M12 connector is B-coded (Reverse key).


PCA-1564927 Straight 2 m PCA-1564930 Straight 6 m PCA-1564943 Right angled 2 m PCA-1564969 Right angled 6 m



SPEEDCON

Straight connector type





pin arrangement B-coded (Reverse key)

.... Brown: 24 VDC +10%/-5% (For output)
White: 0 V (For output)
--- Blue: 24 VDC ±10% (For control and input)
--- Black: 0 V (For control and input)
--- Gray: Functional earth Connections

Socket connector pin arrangement B-coded (Reverse key)

Angled connector type 36.3 22.5 88 92.9 Marker tag M12 ø14.8 SPEEDCON

Terminal no Core wire color --Brown: 24 VDC +10%/-5% (For output) White: 0 V (For output) --Blue: 24 VDC ±10% (For control and input) Black: 0 V (For control and input) ---Gray: Functional earth


Connections

| Item | Specifications |
|---------------------------------|-----------------------------|
| Cable O.D. | ø5.9 mm |
| Conductor nominal cross section | 0.34 mm ² /AWG22 |
| Wire O.D. (Including insulator) | 1.27 mm |
| Min. bending radius (Fixed) | 59 mm |



Power Supply Cable (M12 connector, For EX600-ED4/5)

* The shape of the M12 connector is A-coded (Normal key).




• Connector specification

| u | able | iengtn (L) • |
|---|------|--------------|
| | 010 | 1000 mm |
| | 050 | 5000 mm |


| S | Straight |
|---|----------|
| Α | Angled |
| | |

Straight connector type




| Item | Specifications |
|-------------------------------------|----------------------------|
| Cable O.D. | ø6 mm |
| Nominal cross section | 0.3 mm ² /AWG22 |
| Wire diameter (Including insulator) | 1.5 mm |
| Min. bending radius | 40 mm (Fixed) |

Angled connector type




A-coded (Normal key)


| Item | Specifications |
|-------------------------------------|----------------------------|
| Cable O.D. | ø6 mm |
| Nominal cross section | 0.3 mm ² /AWG22 |
| Wire diameter (Including insulator) | 1.5 mm |
| Min. bending radius | 40 mm (Fixed) |



SPEEDCON




PCA- 1557769 Cable length (L) 1557769 3000 mm



Socket connector pin arrangement

A-coded (Normal key)

| Item | Specifications |
|-------------------------------------|----------------------------|
| Cable O.D. | ø5 mm |
| Nominal cross section | 0.3 mm ² /AWG22 |
| Wire diameter (Including insulator) | 1.27 mm |
| Min. bending radius | 21.7 mm (Fixed) |






Socket connector pin arrangement
A-coded

(Normal key)


Plug connector pin arrangement A-coded (Normal key)



Connections


Accessories EX600 Series


(I) Communication Cable




EX9-AC 005 MJ-SSPS (With connector on both sides (Socket/Plug))











EX9-AC 005 MJ-SAPA (With angled connector on both sides (Socket/Plug))



| Item | | Specifications |
|-----------------------------|-----------|-----------------------------|
| Cable O.D. | | ø7.7 mm |
| Conductor nominal | Data pair | 0.5 mm ² /AWG20 |
| cross section | Drain | 0.34 mm ² /AWG22 |
| Wire O.D. (Including | 2.55 mm | |
| Min. bending radius (Fixed) | | 77 mm |






Socket connector pin arrangement A-coded (Normal key)

*1 Number of holes: 5, Total number of pins: 4

0


000 2


Communication Cable
















EX9-AC 005 DN-SAPA (With angled connector on both sides (Socket/Plug))



| | _ | |
|-----------------------------|------------|-----------------------------|
| Item | | Specifications |
| Cable O.D. | | ø6.7 mm |
| Conductor nominal | Power pair | 0.34 mm ² /AWG22 |
| cross section | Data pair | 0.25 mm ² /AWG24 |
| Wire O.D. | Power pair | 1.4 mm |
| (Including insulator) | Data pair | 1.95 mm |
| Min. bending radius (Fixed) | | 67 mm |







Socket connector pin arrangement A-coded (Normal key)

50


(I) Communication Cable




PCA-1557688

(Socket)

PCA-1557691



S



5000

| Terminal no. | Core wire color | | |
|---------------------------------------|------------------------------|--|--|
| 2 1 4 3 4 5 | Green: A Line Red: B Line | | |
| hield line is connected to the knurl. | | | |
| Connections | | | |

| Item | Specifications |
|---------------------------------|-----------------------------|
| Cable O.D. | ø7.8 mm |
| Conductor nominal cross section | 0.34 mm ² /AWG22 |
| Wire O.D. (Including insulator) | 2.55 mm |
| Min. bending radius (Fixed) | 78 mm |

For EtherCAT® For PROFINET For EtherNet/IP™


Plug connector

pin arrangement

B-coded (Reverse key)


EX9-AC 020 EN-PSRJ (Plug/RJ-45 connector)






| Item | Specifications |
|---------------------------------|-----------------------------|
| Cable O.D. | ø6.4 mm |
| Conductor nominal cross section | 0.14 mm ² /AWG26 |
| Wire O.D. (Including insulator) | 0.98 mm |
| Min. bending radius (Fixed) | 26 mm |

PCA-1446566 (Plug)



| Item | Specifications |
|---------------------------------|----------------|
| Cable O.D. | ø6.5 mm |
| Conductor nominal cross section | AWG22 |
| Wire O.D. (Including insulator) | 1.55 mm |
| Min. bending radius (Fixed) | 45.5 mm |

(I) Communication Cable




Prield-wireable Communication Connector

Plug


For CC-Link For DeviceNet® PCA-1075526 PCA-1075528





For PROFIBUS DP PCA-1075530






Applicable Cable

| Item | Specifications | |
|--|---|--|
| Cable O.D. | 4.0 to 8.0 mm | |
| Wire gauge (Stranded wire cross section) | 0.14 to 0.75 mm²/AWG26 to 18 (Solid cable/Flexible cable) 0.08 to 0.5 mm²/AWG28 to 20 (With ferrule) | |

For EtherCAT® For PROFINET For EtherNet/IP™

PCA-1446553





Applicable Cable

| ſ | Item | Specifications | | |
|---|--|---|--|--|
| ĺ | Cable O.D. | 4.0 to 8.0 mm | | |
| [| Wire gauge (Stranded wire cross section) | 0.14 to 0.34 mm ² /AWG26 to 22 | | |

* The table above shows the specifications for the applicable cable. Adaptation for the connector may vary on account of the conductor construction of the electric wire.


Socket

For CC-Link For DeviceNet®

PCA-1075527 PCA-1075529




(Normal kev)



For PROFIBUS DP PCA-1075531



(Reverse key)



Applicable Cable


| Item | Specifications | | |
|--|---|--|--|
| Cable O.D. | 4.0 to 8.0 mm | | |
| Wire gauge (Stranded wire cross section) | 0.14 to 0.75 mm²/AWG26 to 18 (Solid cable/Flexible cable) 0.08 to 0.5 mm²/AWG28 to 20 (With ferrule) | | |

(B) I/O Cable with Connector, I/O Connector

For details, refer to the Web Catalog.


| Name | Use | Part no. | Description |
|--------------------------|-------------|-------------|---|
| Cable with | For sensor | PCA-1557769 | Cable with M12 connector (4 pins/3 m) |
| connector | | PCA-1557772 | Cable with M8 connector (3 pins/3 m) |
| | | PCA-1557730 | Field-wireable connector (M8/3 pins/Plug/Piercecon® connection) |
| Field-wireable connector | For sensor | PCA-1557743 | Field-wireable connector (M12/4 pins/Plug/QUICKON-ONE connection/SPEEDCON) |
| | 600 | PCA-1557756 | |
| Y connector | For sensor | PCA-1557785 | Y connector (2 x M12 (5 pins)-M12 (5 pins)/SPEEDCON) |
| Y connector | T Connector | PCA-1557798 | Y connector (2 x M8 (3 pins)-M12 (4 pins)/SPEEDCON) |

* When using the Y connector, connect it to the connector on the I/O unit through the sensor cable (PCA-1557769) with the M12 connector.



For IO-Link Unit


1436



(B) I/O Cable with Connector, I/O Connector

Port Class B EX260-SIL SI Unit and Port Class A IO-Link Master Connection Example Port class A Port class B IO-I ink SI unit Port class A compliant EX260-SIL EX600-LAB1 A special wiring Y branch connector is Connect to available the master Connect to the SI unit Connect to **O**IO-Link Used when connecting to a port class A power supply 4 type IO-Link master, which is often used **Branch Connector** when connecting to an IO-Link sensor Power supply load

Y Branch Connector for IO-Link




5 0

1O-Link Device Tool License Key

USB dongle **EX9-ZSW-LDT1**

9



EX600 Series **Made to Order**

Please contact SMC for detailed specifications and lead times.




SI Unit

Prepare the SI unit, each type of unit, and the manifold valve (without SI unit) separately, and combine them before use.

- ① Ethernet POWERLINK compatible EX600-SPL1-X26
 - Dimensions are the same as those of the EX600-SEN3.
- ③ CC-Link IE Field compatible





NPN



② Modbus/TCP compatible EX600-SMT1-X25

• Dimensions are the same as those of the EX600-SEN3.

Communication Cable

With connector on one side (Socket)

Cable length: 10000 mm

For CC-Link For DeviceNet®

EX9-AC100 MJ -X12

Applicable protocol


MJ CC-Link
DN DeviceNet®



Socket connector pin arrangement A-coded (Normal key)

For CC-Link

Dimensions



Connections


| Terminal no. | Core wire color: Signal name (CC-Link) | | |
|--------------|--|--|--|
| 1 | Shield: SLD | | |
| 2 | White: DB | | |
| 3 | Yellow: DG | | |
| 4 | 4 Blue: DA | | |
| | | | |

^{*1} Number of holes: 5, Total number of pins: 4

| Item | | Specifications | |
|---------------------------------|-----------|-----------------------------|--|
| Cable O.D. | | ø7.7 mm | |
| Conductor nominal | Data pair | 0.5 mm ² /AWG20 | |
| cross section | Drain | 0.34 mm ² /AWG22 | |
| Wire O.D. (Including insulator) | | 2.55 mm | |
| Min. bending radius (Fixed) | | 77 mm | |

For DeviceNet®

Dimensions





Socket connector pin arrangement A-coded (Normal key)

Connections

| Terminal no. | Core wire color: Signal name (DeviceNet |
|--------------|---|
| 1 | Shield: DRAIN |
| 2 | Red: V+ |
| 3 | Black: V- |
| 4 | White: CAN H |
| 5 | Blue: CAN L |
| | |

| Item | | Specifications | |
|-----------------------------|------------|-----------------------------|--|
| Cable O.D. | | ø6.7 mm | |
| Conductor nominal | Power pair | 0.34 mm ² /AWG22 | |
| cross section | Data pair | 0.25 mm ² /AWG24 | |
| Wire O.D. | Power pair | 1.4 mm | |
| (Including insulator) | Data pair | 2.05 mm | |
| Min. bending radius (Fixed) | | 67 mm | |



EX600 Series Specific Product Precautions

Be sure to read this before handling the products. Refer to page 7 for safety instructions and pages 15 to 17 for fieldbus system precautions.

Mounting

- 1. When handling and assembling units, do not touch the sharp metal parts of the connector or plug.
- When connecting six stations or more, be sure to use the intermediate reinforcing brace (EX600-ZMB1 or EX600-ZMB2).

Operating Environment

 Select the proper type of enclosure according to the operating environment.

IP65/67 is achieved when the following conditions are met.

- Provide appropriate wiring between all units using electrical wiring cables, communication connectors and cables with M12 connectors.
- 2) Appropriately mount each unit and valve manifold.
- 3) Be sure to mount a seal cap on any unused connectors. If using in an environment that is exposed to water splashes, please take measures such as using a cover.

When the enclosure is IP40, do not use in an operating environment or atmosphere where it may come in contact with corrosive gas, chemical agents, seawater, water, or water vapor. When connected to the EX600-DDDD or EX600-DDDD, manifold enclosure is IP40.

Also, the handheld terminal conforms to IP20, so prevent foreign matter from entering inside, and water, solvent or oil from coming in direct contact with it.

Adjustment / Operation

∧ Warning

<Handheld Terminal>

1. Do not apply pressure to the LCD.

There is a possibility of the crack of LCD and injuring.

2. The forced input/output function is used to change the signal status forcibly. When operating this function, be sure to check the safety of the surroundings and installation.

This may cause injuries or equipment damage.

 Incorrect setting of parameters can cause a malfunction. Be sure to check the settings before use.

This may cause injuries or equipment damage.

⚠ Caution

<Handheld Terminal>


 Do not press the setting buttons with a sharp pointed object.

This may cause damage or equipment failure.

Do not apply excessive load and impact to the setting buttons.

This may cause damage, equipment failure or malfunction.

When the order does not include the SI unit, a valve plate which connects the manifold and SI unit, is not mounted. Use attached valve holding screws and mount the valve plate. (Tightening torque: 0.6 to 0.7 N-m)



Screw tightened parts
SV series: 2 places
SV700 series: 2 places
VQC1000 series: 2 places
VQC2000 series: 3 places
VQC4000 series: 4 places
VQC5000 series: 4 places
SY series: 2 places
SY series: 2 places
ZK2□A series: 2 places

■Trademark
DeviceNet[®] is a registered trademark of ODVA. Inc.

EtherNetIP® is a registered trademark of ODVA, Inc.

EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany. Modbus® is a registered trademark of Schneider Electric, licensed to the Modbus Organization, Inc.

QuickConnect™ is a trademark of ODVA.

